Package 'UKFE'

February 9, 2025

Type Package

Title UK Flood Estimation

Version 0.4.0

Maintainer Anthony Hammond <agqhammond@gmail.com>

Description Functions to implement the methods of the Flood Estimation Handbook (FEH), associated updates and the revitalised flood hydrograph model (ReFH). Currently the package uses NRFA peak flow dataset version 13. Aside from FEH functionality, further hydrological functions are available. Most of the methods implemented in this package are described in one or more of the following: ``Flood Estimation Handbook", Centre for Ecology & Hydrology (1999, ISBN:0 948540 94 X). ``Flood Estimation Handbook Supplementary Report No. 1", Kjeldsen (2007, ISBN:0 903741 15 7). ``Regional Frequency Analysis an approach based on L-moments", Hosking & Wallis (1997, ISBN: 978 0 521 01940 8). ``Proposal of the extreme rank plot for extreme value analysis: with an emphasis on flood frequency studies", Hammond (2019, <doi:10.2166/nh.2019.157>). ``Making better use of local data in flood frequency estimation", Environment Agency (2017, ISBN: 978 1 84911 387 8). ``Sampling uncertainty of UK design flood estimation", Hammond (2021, <doi:10.2166/nh.2021.059>). ``Improving the FEH statistical procedures for flood frequency estimation", Environment Agency (2008, ISBN: 978 1 84432 920 5). ``Low flow estimation in the United Kingdom", Institute of Hydrology (1992, ISBN 0 948540 45 1). Wallingford HydroSolutions, (2016, <http://software.hydrosolutions.co.uk/winfap4/</pre> Urban-Adjustment-Procedure-Technical-Note.pdf>). Data from the UK National River Flow Archive (<https://nrfa.ceh.ac.uk/>, terms and conditions: <https://nrfa.ceh.ac.uk/costs-terms-and-conditions>).

License GPL-3

Encoding UTF-8

LazyData true

RoxygenNote 7.3.2

Depends R (>= 3.5.0)

Imports xml2, methods, sf

NeedsCompilation no

Author Anthony Hammond [aut, cre]

Repository CRAN Date/Publication 2025-02-09 15:30:02 UTC

Contents

AddGauge
AggDayHour
$MImport \dots \dots$
$\mathbf{M} plot \dots \dots$
MSP
AnnualStat
ARF
BFI
Bootstrap
CDsXML 13
ConvertGridRef
DDF
DDF99
DF99
DDFExtract 18 NDFL 10
DDFImport
DesHydro
DeTrend
DiagPlots
DonAdj
EncProb
RPlot
20 Plot
27 WPlotAdd
29 WPool
'lowDurationCurve
YlowSplit
GenLogAM
GenLogEst
GenLogGF
GenLogPars
GenParetoEst
GenParetoGF
GenParetoPars
GenParetoPOT
GetAM
GetCDs
GetDataEA_QH
GetDataEA_Rain
SetDataMetOffice
GetDataNRFA
GetDataSEPA_QH
$\operatorname{potDutubDiff}_{211}$

GetDataSEPA_Rain	49
GetQMED	50
GEVAM	51
GEVEst	52
GEVGF	53
GEVPars	54
GoFCompare	55
GoFComparePool	
GumbelAM	
GumbelEst	
GumbelGF	
GumbelPars	
H2	
HydroPlot	
Kappa3AM	
Kappa3Est	
Kappa3GF	
Kappa3Pars	
11	
Lev	
LcvUrb	
LKurt	
LMoments	
LRatioChange	
LSkew	
LSkewUrb	
MonthlyStats	
NGRDist	
NonFloodAdj	
NonFloodAdjPool	76
NRFAData	
OptimPars	
Pool	79
PoolEst	80
PoolSmall	82
POTextract	84
POTt	85
QMED	87
QMEDData	88
QMEDDonEq	89
QMEDfseSS	90
QMEDLink	91
QMEDPOT	92
QuickResults	93
Rating	94
ReFH	95
SCF	
SimData	
ThamesPQ	

TrendTest
UAF
UEF
UKOutline
Uncertainty
WeightsGLcv
WeightsGLSkew
WeightsUnLcv
WeightsUnLSkew
WGaugLcv
WGaugLSkew
WungLcv
WungLSkew
Zdists
113

Index

```
AddGauge
```

Add an AMAX sample

Description

This function allows the user to add an AMAX sample and associated catchment descriptors for use with the FEH process.

Usage

AddGauge(CDs, AMAX, ID)

Arguments

CDs	catchment descriptor object imported using the CDsXML function.
AMAX	Either a data.frame with date (or POSIXct) in the first column and a numeric
	vector in the second (the AMAX). Or an AMAX sample (a numeric vector).
ID	This is a user supplied identification number for the AMAX.

Details

The function provides the necessary AMAX sample statistics and data.frame for adding catchment descriptors to the NRFAData data.frame. The user must then add these outputs using the rbind function (see example). The AMAX could be read in or pasted in by the user or imported using the AMImport function. Once they are added they can be used in the current R session. If a new session is started (rather than a saved workspace) the added AMAX would need to be added again.

Value

A list object. The first element is a data.frame which is a row of statistics and descriptors to be added to the NRFAData data.frame. The second element is the AMAX sample formatted to be added to the AMSP data.frame

AggDayHour

Author(s)

Anthony Hammond

Examples

```
#Read in AMAX and catchment descriptors
## Not run: AMAdd <- AMImport(r"{D:\NRFAPeakFlow_v12_1_0\suitable-for-neither\027003.am}")
## Not run: CDsAdd <- CDsXML(r"{D:\NRFAPeakFlow_v12_1_0\suitable-for-neither\027003.xml}")
#Apply the function and then add the results to the necessary data.frames.
## Not run: Gauge27003 <- AddGauge(CDsAdd, AMAdd, ID = "27003")
#Add the descriptors and stats (the first element of the output) to the NRFAData data.frame
## Not run: NRFAData <- rbind(NRFAData, Gauge27003[[1]])
#Add the AMAX to the AMSP data.frame.
## Not run: AMSP <- rbind(AMSP, Gauge27003[[2]])</pre>
```

```
AggDayHour
```

Aggregate a time series

Description

Aggregates time series data, creating hourly data from 15 minute data for example.

Usage

AggDayHour(x, func, Freq = "Day", hour = 9)

Arguments

х	a data.frame with POSIXct in the first column and numeric vector in the second.
func	the function used for aggregation; mean, max, or sum, for example.
Freq	Choices are "Day", or "Hour".
hour	An integer between 0 and 23. This is used if "Day" is chosen in the Freq argument to determine when the day starts.

Details

The function can be used with a data.frame with POSIXct in the first column and a variable in the second. You can choose the level of aggregation in hours, or you can choose daily. In the daily case you can choose which hour of the day to start the aggregation. For example, you might want mean flows from 09:00 rather than midnight. You can also choose the function used to aggregate the data. For example, you might want "sum" for rainfall, and "mean" for flow. When aggregating hourly the aggregation starts at whatever hour is in the first row of x and the associated time stamps will reflect this.

Value

A data.frame with POSIXct in the first column (unless daily is chosen, then it's Date class), and the aggregated variable in the second column

Author(s)

Anthony Hammond

Examples

```
#Create a data.frame with a normally distributed variable at
#a 15 minute sampling rate.
TS <- seq(as.POSIXct("2000-01-01 00:00:00",
tz = "Europe/London"), as.POSIXct("2001-01-01 00:00:00", tz = "Europe/London"), by = 60*15)
TS <- data.frame(DateTime = TS, Var = rnorm(length(TS), 10, 2))
#use the function to aggregate to an hourly sampling rate, taking the maximum of each hour
Hourly <- AggDayHour(TS, func = max, Freq = "Hour")
#now aggregate with the mean at a daily scale
Daily <- AggDayHour(TS, func = mean, Freq = "Day")</pre>
```

AMImport	Import an annual maximum	(AMAX) sample from NRFA peak flow
	.AM files	

Description

Imports the peak flows and dates from from NRFA peak flow .AM files, exluding the rejected years

Usage

AMImport(x)

Arguments

х

the file path for the .AM file

Details

File paths for importing data require forward slashes. On some operating systems, such as windows, the copy and pasted file paths will have backward slashes and would need to be changed accordingly.

Value

A data.frame with columns; Date and Flow

Author(s)

Anthony Hammond

AMplot

Examples

```
#Import an AMAX sample and display the first six rows in the console
## Not run: AM.4003 <- AMImport("C:/Data/NRFAPeakFlow_v11/Suitable for QMED/4003.AM")
## Not run: head(AM.4003)]</pre>
```

AMplot

Plot of the annual maximum sample

Description

Provides a barplot for an annual maximum sample

Usage

```
AMplot(x, ylab = "Discharge (m3/s)", xlab = "Hydrological year", main = NULL)
```

Arguments

x	A data.frame with at least two columns. The first a date column and the second the annual maximum (AM) sequence. A third column with the station id can be applied which is then used for the default plot title.
ylab	Label for the y axis (character string).
xlab	Label for the x axis (character string).
main	Title for the plot (character string). The default is 'Annual maximum sample:', where : is followed by an ID number if this is included in a third column of the dataframe x.

Details

When used with a GetAM object or any data.frame with dates/POSIXct in the first column, the date-times are daily or sub-daily. Therefore, although it's an annual maximum (AM) sequence, some bars may be closer together depending on the number of days between them.

Value

A barplot of the annual maximum sample

Author(s)

Anthony Hammond

Examples

#Get an AMAX sample and plot AMplot(GetAM(58002)) AMSP

National River Flow Archive (NRFA) annual maximum data for sites suitable for pooling

Description

A data.frame with three columns; Date, Flow, id. NRFA Peak Flow Dataset - Version 13.0.2

Usage

AMSP

Format

A data frame with 26539 rows and 3 columns

Date Date

Flow Annual maximum peak flow, m3/s

id Station identification number

Source

https://nrfa.ceh.ac.uk/peak-flow-dataset

AnnualStat Annual statistics extraction

Description

Extracts annual statistics (default maximums) from a data.frame which has dates (or POSIXct) in the first column and variable in the second.

Usage

```
AnnualStat(
    x,
    Stat = max,
    Truncate = TRUE,
    Mon = 10,
    Hr = 9,
    Sliding = FALSE,
    N = 24,
    ...
)
```

AnnualStat

Arguments

x	a data.frame with dates (or POSIXct) in the first column and variable in the second
Stat	A user chosen function to extract statistics, for example mean. The default it max. User supplied functions could also be used.
Truncate	Logical argument with a default of TRUE. If TRUE, then x is truncated to be within the first and last occurrence of the chosen month and time. If FALSE tuncation is not done and results from partial years will be included.
Mon	Choice of month as a numeric, from 1 to 12. The default is 10 which means the year starts October 1st.
Hr	Choice of hour to start the year (numeric from 0 to 23). The default is 9.
Sliding	Logical argument with a default of FALSE. This can be applied if you want the statistic over a sliding period. For example, deriving maximum annual rainfall totals over a 24 hour period, rather than the maximum daily totals. The number of periods (timesteps) is chosen with the N argument. If for example you want the annual maximum sum of rainfall over a 24 hour period, and you have 15minute data, the Stat input would be sum, and N would be 96 (because there are 96 15 minute periods in 24 hours).
Ν	Number of timesteps to slide over - used in conjunction with Sliding. The default is 24, make sure to adjust this depending on the duration of interest and the sampling rate of the input data.
	further arguments for the stat function. Such as na.rm = TRUE.

Details

The statistics are extracted based on the UK hydrological year by default (start month = 10). Month can be changed using the Mon argument. A year is from Mon-Hr to Mon-(Hr-1). For example, the 2018 hydrological year with Hr = 9 would be from 2018-10-01 09:00:00 to 2019-10-01 08:00:00. If Hr = 0, then it would be from 2018-10-01 00:00:00 to 2019-09-30 23:00:00. Data before the first occurrence of the 'start month' and after and including the last occurrence of the 'start month' is not included in the calculation of the statistic.

Value

a data.frame with columns; DateTime and Result. By default Result is the annual maximum sample, but will be any statistic used as the Stat argument.

Author(s)

Anthony Hammond

```
#Extract the Thames AMAX daily mean flow and display the first six rows
ThamesAM <- AnnualStat(ThamesPQ[,c(1,3)])
head(ThamesAM)
#Extract the annual rainfall totals.
```

```
ThamesAnnualP <- AnnualStat(ThamesPQ[,1:2], Stat = sum)
#Extract maximum five day rainfall totals from the Thames rain
ThamesP5DayAM <- AnnualStat(ThamesPQ[,1:2], Stat = sum, Sliding = TRUE, N = 5)
```

ARF

Areal reduction factor (ARF)

Description

The results of applying, to a rainfall depth, the ratio of the rainfall over an area to the rainfall depth of the same duration at a representative point in the area.

Usage

ARF(Depth, Area, D)

Arguments

Depth	depth of rainfall
Area	catchment area in km2
D	duration in hours

Details

The ARF and it's use is detailed in the Flood Estimation Handbook (1999), volume 2. The DDF model is calibrated on point rainfall and the areal reduction factor converts it to a catchment rainfall for use with a rainfall runoff model such as ReFH (see details for ReFH function). The ReFH model includes a design rainfall profile for winter and summer but the depth duration frequency (DDF) model is calibrated on annual maximum peaks as opposed to seasonal peaks. A seasonal correction factor (SCF) is necessary to convert the DDF estimate to a seasonal one. The final depth, therefore is; Depth = DDFdepth x ARF x SCF.

Value

the rainfall depth or rainfall return period

Author(s)

Anthony Hammond

```
#Derive the ARF for a depth of 30, an area of 500km2 and a duration of 12 hours ARF(30, 500, 12)
```

BFI

Description

Calculates the baseflow index from a daily mean flow series

Usage

BFI(Q, x.lim = NULL, y.lim = NULL, PlotTitle = "Baseflow plot", Plot = TRUE)

Arguments

Q	the daily mean flow series. Numeric vector
x.lim	the x axis limits of the plot. Numeric vector of length two Default is the extents of the data
y.lim	the y axis limits of the plot. Numeric vector of length two. Default is the extents of the data
PlotTitle	the title of the plot. The default is "Baseflow plot"
Plot	a logical argument with a default of TRUE. If TRUE the daily flow is plotted with the baseflow highlighted.

Details

The baseflow index is calculated using the method outlined in Gustard, A. Bullock, A. Dixon, J. M. (1992). Low flow estimation in the United Kingdom. Wallingford, Institute of Hydrology, 88pp. (IH Report No.108)

Value

the baseflow index and if Plot equals TRUE, a plot showing the flow time series (black) and the associated baseflow (red)

Author(s)

Anthony Hammond

Examples

Calculate the BFI from daily discharge at Kingston upon Thames; # which is in column three of the ThamesPQ data BFI(ThamesPQ[,3]) Bootstrap

Description

Resampling with replacement to approximate the sampling distribution of a statistic and quantify uncertainty.

Usage

Bootstrap(x, Stat, n = 500, Conf = 0.95, ReturnSD = FALSE, ...)

Arguments

x	a numeric vector. The sample of interest
Stat	the function (to calculate the statistic) to be applied to the bootstrapped samples. For example mean, max, or median.
n	the number of boostrapped samples (default 500). i.e. the size of the derived sampling distribution.
Conf	the confidence level of the intervals (default 0.95). Must be between 0 and 1.
ReturnSD	Logical argument with a default of FALSE. If true the bootstrapped sampling distribution is returned.
	further arguments for the Stat function. For example if you use the GEVAM function you might want to add $RP = 50$ to derive a sampling distribution for the 50-year quantile.

Details

The bootstrapping procedure resamples from a sample length(x) * n times with replacement. After splitting into n samples of size length(x), the statistic of interest is calculated on each.

Value

If ReturnSD is FALSE a data.frame is returned with one row and three columns; central, lower, and upper. If ReturnSD is TRUE, the sampling distribution is returned.

Author(s)

Anthony Hammond

CDsXML

Examples

```
#Extract an AMAX sample and quantify uncertainty for the Gumbel estimated 50-year flow.
AM.203018 <- GetAM(203018)
Bootstrap(AM.203018$Flow, Stat = GumbelAM, RP = 50)
#Quantify uncertainty for the sample standard deviation at the 90 percent confidence level
Bootstrap(AM.203018$Flow, Stat = sd, Conf = 0.90)
#Return the sampling distribution of the mean and plot an associated histogram
SampDist <- Bootstrap(AM.203018$Flow, Stat = mean, ReturnSD = TRUE)
hist(SampDist)
```

CDsXML

Import catchment descriptors from .xml files

Description

Imports catchment descriptors from xml files either from an FEH webservice download or from the Peakflows dataset downloaded from the national river flow archive (NRFA) website

Usage

CDsXML(x)

Arguments

х

the xml file path

Details

File paths for importing data require forward slashes. On some operating systems, such as windows, the copy and pasted file paths will have backward slashes and would need to be changed accordingly.

Value

A data.frame with columns; Descriptor and Value.

Author(s)

Anthony Hammond

```
#Import catchment descriptors from a NRFA peakflows xml file and display in console
## Not run: CDs.4003 <- CDsXML("C:/Data/NRFAPeakFlow_v11/Suitable for QMED/4003.xml")
## Not run: CDs.4003
#Import catchment descriptors from a FEH webserver xml file and display xml in the console
## Not run: CDs.MySite <- CDsXML("C:/Data/FEH_Catchment_384200_458200.xml")</pre>
```

ConvertGridRef

Convert between British National Grid Reference (BNG) and Latitude and Longitude or Irish Grid references.

Description

Function to convert between BNG easting & northing and Latitude & Longitude (or vice versa). Or to convert between BNG and Irish national grid (or vice versa)

Usage

ConvertGridRef(x, fromBNG = TRUE, IGorLatLon = "LatLon")

Arguments

x	A vector of length 2. Either latitude and longitude (if fromBNG = FALSE) or BNG easting and northing (if fromBNG = TRUE). Or Irish easting and northing if IGorLatLon is set to IG and fromBNG = FALSE.
fromBNG	A logical argument with a default of TRUE. When TRUE it converts from BNG easting and northing to latitude and longitude (or to IG easting and northing if IGorLatLon is set to "IG"). When FALSE it converts the other way round.
IGorLatLon	This argument allows you to choose between Latitude & Longitude and Irish grid reference. The acceptable options are "LatLon" or "IG". If you choose "IG" you are converting between BNG and IG. If you choose "LatLon", you are converting between BNG and Lat Lon.

Details

To convert to Lat and Lon from BNG, ensure that the fromBNG argument is TRUE. To convert the other way, set fromBNG as FALSE. The same applies for converting between Irish grid and BNG. To convert Irish grid and BNG set the IGorLatLon argument to IG.

Value

A data.frame with the converted grid references. Either latitude and longitude if BNG = TRUE. Or BNG easting and northing if fromBNG = FALSE. Or, IG easting & northing if fromBNG = TRUE and IGorLatLon = "IG".

Author(s)

Anthony Hammond

```
#Get Latitude and Longitude for a BNG numeric reference.
ConvertGridRef(c(462899, 187850))
#Now we'll get easting and northing as a function of latitude and longitude
ConvertGridRef(c(51.6, -1), fromBNG = FALSE)
```

DDF

Description

Extracts results from a data frame imported using the DDFImport function

Usage

DDF(x, duration, RP = 100)

Arguments

x	A data frame of DDF13 or DDF22 results imported using the DDFImport func- tion
duration	the duration (hrs) for which a rainfall depth estimate is required
RP	the return period (years) for which a rainfall depth estimate is required

Details

The .xml files only provide a set number of durations and return periods for DDF13 and DDF22. This function optimises the GEV distribution on the results in order to interpolate across return periods. A linear interpolation is used between durations. The interpolation method may provide results that differ from the FEH webserver in the region of 0.1mm. The result is then rounded to an integer.

Value

A DDF13 or DDF22 estimate of rainfall depth (mm)

Author(s)

Anthony Hammond

```
#Get DDF13 results from a the DDF
## Not run: DDF13.4003 <- DDFImport("C:/Data/NRFAPeakFlow_v9/Suitable for QMED/04003.xml")
#Estimate the 20-year, 5 hour depth
## Not run: DDF(DDF13.4003, duration = 5, RP = 20)</pre>
```

Description

Estimation of design rainfall depths, and the rarity of observed rainfall

Usage

DDF99(Duration, RP, pars, Depth = NULL, disc = NULL)

Arguments

Duration	numeric. The duration of interest (in hours)
RP	return period
pars	a numeric vector of length six. The six catchment parameters for the DDF model in the order of: c, d1, d2, d3, e, f
Depth	a user supplied rainfall depth for the duration under question
disc	converts from the sliding duration to fixed duration estimate. Choices are "hourly" or "daily"

Details

The depth duration frequency rainfall model is detailed in the Flood Estimation Handbook (1999), volume 2. A note about the discretisation: The user can choose between "daily" or "hourly" for the sliding duration to fixed duration conversion. If the 'Depth' argument is used, it overrides the return period (RP) argument and provides RP as a function of depth. However, if both the 'Depth' and the 'disc' arguments are used, the sliding duration depth is provided as a function of the user input depth. This resulting depth can then be used without the 'disc' argument to determine the sliding duration RP.

Value

the rainfall depth or rainfall return period

Author(s)

Anthony Hammond

```
#Examples from FEH volume 2
#The parameters for these examples are from FEH v2
#What is the 2-day rainfall with return period 100-years for Norwich.
DDF99(Duration = 48, RP = 100, pars = c(-0.023, 0.273, 0.351, 0.236, 0.309, 2.488))
#What is the 4-hour rainfall with return period 20 years for a typical point in the Lyne catchment
DDF99(Duration = 4, RP = 20, pars = c(-0.025, 0.344, 0.485, 0.402, 0.287, 2.374))
```

DDF99Pars

```
#How rare was the rainfall of 6th August 1978 at Broughshane, County Antrim?
DDF99(Duration = 5, Depth = 47.7, pars = c(-0.022, 0.412, 0.551, 0.276, 0.261, 2.252))
```

DDF99Pars

DDF99 parameters from .xml files

Description

Imports the FEH 1999 depth duration frequency parameters from xml files either from an FEH webservice download or from the Peakflows dataset downloaded from the national river flow archive (NRFA) website

Usage

DDF99Pars(x)

Arguments ×

the xml file path

Details

This function is coded to import DDF99 parameters from xml files from the NRFA or the FEH webserver. File paths for importing data require forward slashes. On some operating systems, such as windows, the copy and pasted file paths will have backward slashes and would need to be changed accordingly.

Value

A list with two elements, each a data frame with columns; parameters and associated Values The first data frame is for the catchment average parameters (these still require an ARF adjustment where appropriate) and the second for the 1km2 grid point parameters.

Author(s)

Anthony Hammond

```
#Import DDF99 parameters from a NRFA peakflows xml file and display in console
## Not run: DDF99.4003 <- DDF99Pars("C:/Data/NRFAPeakFlow_v11/Suitable for QMED/04003.xml")
## Not run: DDF99.4003
#Import DDF99 parameters from a FEH webserver xml file and display in the console
## Not run: DDF99.MySite <- DDF99Pars("C:/Data/FEH_Catchment_384200_458200.xml")</pre>
```

DDFExtract

Description

Derive and plot rainfall Depth Duration Frequency curves from an input of rainfall data.

Usage

DDFExtract(x, Plot = TRUE, main = NULL, Truncate = TRUE)

Arguments

х	A data.frame with POSIXct in the first column and rainfall in the second. The data must have an hourly or sub-hourly sampling rate.
Plot	Logical argument with a default of TRUE. If TRUE, the DDF curves are plotted.
main	Title for the plot (character string). The default is no title.
Truncate	Logical argument with a default of TRUE. If TRUE the extraction of annual maximum process truncates the data to incorporate only full hydrological years. If there is significant rainfall within a partial year it will not be included unless Truncate = FALSE. If Truncate = FALSE, ensure that there are at least 92 hours of data available in the partial years or the function will fail.

Details

The function works by extracting the annual maximum sample (by hydrological year - starting Oct 1st) of rainfall for a range of sliding durations (1 hour to 96 hours). It then calculates the median annual maximum rainfall depth (RMED) and a GEV growth curve for each duration. To ensure RMED increases with duration a power curve is fit as a function of duration to provide the final RMED estimates. Then the average growth factor for each return period (across the durations) is assumed.

Value

A dataframe with hours (1 to 96) in the first column then depths associated with a range of return periods (2 to 1000) in the remaining nine columns. If Plot = TRUE, a plot of the DDF curves is also returned.

Author(s)

Anthony Hammond

DDFImport

Examples

```
# We'll extract all available 15 minute rainfall from the St Ives (Cambridgeshire)
#rain gauge (WISKI ID = 179365).
## Not run: StIves <- GetDataEA_Rain(WISKI_ID = "179365", Period = "15Mins")
#Then apply the DDF function.
## Not run: DDFExtract(StIves)</pre>
```

```
DDFImport
```

DDF13 or DDF22 results from .xml files

Description

Imports the depth duration frequency 2013 or 2022 results from xml files either from an FEH webservice download or from the Peakflows dataset downloaded from the national river flow archive (NRFA) website

Usage

DDFImport(x, ARF = FALSE, Plot = TRUE, DDFVersion = 22)

Arguments

х	the xml file path
ARF	logical argument with a default of FALSE. If TRUE, the areal reduction factor is applied to the results. If FALSE, no area reduction factor is applied
Plot	logical argument with a default of TRUE. If TRUE the DDF curve is plotted for a few return periods
DDFVersion	Version of the DDF model (numeric). either 22 or 13. The default is 22.

Details

This function returns a data-frame of results. For further durations and return periods the separate DDF function can be applied with the data-frame as the argument/input. File paths for importing data require forward slashes. On some operating systems, such as windows, the copy and pasted file paths will have backward slashes and would need to be changed accordingly.

Value

A data frame of DDF results (mm) with columns for duration and rows for return period. If Plot equals TRUE a DDF plot is also returned.

Author(s)

Anthony Hammond

Examples

```
#Import DDF22 results from a NRFA peakflows xml file and display in console
## Not run: DDF22.4003 <- DDFImport("C:/Data/NRFAPeakFlow_v11/Suitable for QMED/04003.xml")
## Not run: DDF22.4003
#Import DDF22 results from a FEH webserver xml file and display in the console
## Not run: DDF22.MySite <- DDFImport("C:/Data/FEH_Catchment_384200_458200.xml")</pre>
```

DesHydro

Design hydrograph extraction

Description

Extracts a mean hydrograph from a flow series

Usage

```
DesHydro(
    x,
    Threshold = 0.975,
    EventSep,
    N = 10,
    Exclude = NULL,
    Plot = TRUE,
    main = "Design Hydrograph"
)
```

Arguments

х	a dataframe with Date or POSIXct in the first coumn and the numeric vector of discharge in the second
Threshold	The threshold above which the peaks of the hydrograph are first identified. The default is 0.975.
EventSep	Number of timesteps to determine individual peak events during the extraction process. For the comparison and averaging process the start and end point of the hydrograph is Peak - EventSep and Peak + EventSep * 1.5.
Ν	number of event hydrographs from which to derive the mean hydrograph. Default is 10. Depending on the length of x, there may be fewer than 10
Exclude	An index (single integer or vector of integers up to N) for which hydrographs to exclude if you so wish. This may require some trial and error. You may want to increase N for every excluded hydrograph.
Plot	logical argument with a default of TRUE. If TRUE, all the hydrographs from which the mean is derived are plotted along with the mean hydrograph.
main	Title for the plot

20

DeTrend

Details

All the peaks over the threshold (default 0.975th) are identified and separated by a user defined value 'EventSep', which is a number of timesteps (peaks are separated by EventSep * 3). The top N peaks are selected and the hydrographs are then extracted. The hydrograph start is the time of peak minus EventSep. The End of the hydrograph is time of peak plus EventSep times 1.5. All events are scaled to have a peak flow of one, and the mean of these is taken as the scaled design hydrograph.

Value

a list of length three. The first element is a dataframe of the peaks of the hydrographs and the associated dates. The second element is a dataframe with all the scaled hydrographs, each column being a hydrograph. The third element is the averaged hydrograph

Author(s)

Anthony Hammond

Examples

#Extract a design hydrograph from the Thames daily mean flow. Then print the resulting hydrograph ThamesDesHydro <- DesHydro(ThamesPQ[,c(1,3)], EventSep = 10, N = 10)

DeTrend

Linearly detrend a sample

Description

Applies a linear detrend to a sample

Usage

DeTrend(x)

Arguments ×

a numeric vector

Details

Adjusts all the values in the sample, of size n, by the difference between the linearly modelled ith data point and the linearly modelled nth data point.

Value

A numeric vector which is a linearly detrended version of x.

Author(s)

Anthony Hammond

Examples

```
# Get an annual maximum (AM) sample that looks to have a significant trend
AM.21025 <- GetAM(21025)
# plot the resulting AM as a bar plot. Then detrend and compare with another plot
plot(AM.21025$Flow, type = "h", ylab = "Discharge (m3/s)")
AM.Detrend <- DeTrend(AM.21025$Flow)
plot(AM.Detrend, type = "h", ylab = "Discharge (m3/s)")
```

DiagPlots Diagnostic plots for pooling groups

Description

Provides 10 plots to compare the sites in the pooling group

Usage

DiagPlots(x, gauged = FALSE)

Arguments

x	pooling group derived from the Pool() function
gauged	logical argument with a default of FALSE. TRUE adds the top site in the pooling group to the plots in a different colour

Value

ten diagnostic plots for pooling groups

Author(s)

Anthony Hammond

```
#Form a gauged pooling group and plot the diagnostics with gauged = TRUE
Pool.28015 <- Pool(GetCDs(28015))
DiagPlots(Pool.28015, gauged = TRUE)
#Form an ugauged pooling group and plot the diagnostics
Pool.28015 <- Pool(GetCDs(28015), exclude = 28015)
DiagPlots(Pool.28015)</pre>
```

Description

Provides donor adjustment candidates, descriptors, and results in order of the proximity to the centroid of the subject catchment.

Usage

DonAdj(CDs = NULL, x, y, QMEDscd = NULL, alpha = TRUE, rows = 10, d2 = NULL)

Arguments

CDs	catchment descriptors derived from either GetCDs or CDsXML
x	catchment centroid easting (for when CDs isn't used)
У	catchment centroid northing (for when CDs isn't used)
QMEDscd	QMED estimate for the catchment of interest (for when CDs isn't used)
alpha	logical argument with a default of TRUE. If FALSE the exponent of the donor adjustment equation is set to one
rows	number of sites provided; default is 10
d2	a numeric vector of length two; the two site references for the donor catchments chosen for the two donor case

Details

When d2 is FALSE the results for single donor adjustment are in the final column headed 'QMED.adj' for each site. If alpha is set to FALSE, the results in this column are from the same donor equation but with an exponent of 1. The donor adjustment method is as outlined in Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation. The method for two donors is outlined in 'Kjeldsen, T. (2019). Adjustment of QMED in ungauged catchments using two donor sites. Circulation - The Newsletter of the British Hydrological Society, 4'. When two donors are used, only the result is returned, rather than donor candidates. The QMEDfse column provides the gauged factorial standard error for the median of the annual maximum sample. It is worth considering this when choosing a donor site (a high value indicates a poor donor). When choosing between two donors, the site with a lower QMEDfse would be an appropriate choice (all else being equal). The QMEDfse is calculated with the QMEDfseSS() function.

Value

A data.frame with rownames of site references and columns of catchment descriptors, distance from subect site, and associated results. When two donors are used, only the resulting adjusted QMED is returned

Author(s)

Anthony Hammond

Examples

```
#Get some CDs and output candidate donor sites
CDs.54022 <- GetCDs(54022)
DonAdj(CDs.54022)
#Get results with inputs of x,y, and QMEDscd
DonAdj(x = 283261, y = 288067, QMEDscd = 17.931)
#Get a result with two donors
DonAdj(CDs.54022, d2 = c(54092, 54091))
```

EncProb	Encounter probabilities	
---------	-------------------------	--

Description

Calculates the probability of experiencing at least n events with a given return period (RP), over a given number of years

Usage

EncProb(n, yrs, RP, dist = "Poisson")

Arguments

n	number of events
yrs	number of years
RP	return period of the events
dist	choice of probability distribution. Either "Poisson" or "Binomial"

Details

The choice of binomial or Poisson distributions for calculating encounter probablities is akin to annual maximum (AM) versus peaks over threshold (POT) approaches to extreme value analysis. AM and binomial assume only one "event" can occur in the blocked time period. Whereas Poisson and POT don't make this assumption. In the case of most catchments in the UK, it is rare to have less than two independent "events" per year; in which case the Poisson and POT choices are more suitable. In large catchments, with seasonally distinctive baseflow, there may only be one independent peak in the year. However, the results from both methods converge with increasing magnitude, yielding insignificant difference beyond a 20-year return period.

Value

A probability

ERPlot

Author(s)

Anthony Hammond

Examples

```
#Calculate the probability of exceeding at least one 50-yr RP event
#over a 10 year period, using the Poisson distribution.
EncProb(n = 1, yrs = 10, RP = 50)
#Calculate the probability of exceeding at least two 100-yr RP events
#over a 100 year period, using the binomial distribution.
EncProb(n = 2, yrs = 100, RP = 100, dist = "Binomial")
```

ERPlot	Extreme rank plot	
--------	-------------------	--

Description

A plot to inspect the distribution of ordered data

Usage

```
ERPlot(x, dist = "GenLog", main = NULL, Pars = NULL, GF = NULL, ERType = 1)
```

Arguments

x	numeric vector. A sample for inspection
dist	a choice of distribution. The choices are "GenLog" (the default), "GEV", "Kappa3,"Gumbel", and "GenPareto"
main	a character string to change the default title, which is the distribution choice.
Pars	a vector of parameters for the distribution. In the order of location, scale, & shape (ignoring the latter if Gumbel). If left null the parameters are estimated from x.
GF	a vector of length growth curve parameters, in the order of; Lcv, LSkew and Median (ignoring the LSkew if Gumbel).
ERType	Either 1, 2. If it is the defaul 1 then ranks are plotted on the x axis and percentage difference of modelled from observed is plotted on the y axis.

Details

By default this plot compares the percentage difference of simulated results with observed for each rank of the data. Another option (see ERType argument) compares the simulated flows for each rank of the sample with the observed of the same rank. For both plots 500 simulated samples are used. With the second option for each rank they are plotted and the mean of these is highlighted in red. There is a line of perfect fit so you can see how much this "cloud" of simulation differs from the observed. By default the parameters of the distribution for comparison with the sample are estimated from the sample. However, the pars argument can be used to compare the distribution with

parameters estimated separately. Similarly the growth factor (GF) parameters, linear coefficient of variation (Lcv) & linear skewness (LSkew) with the median can be entered. In this way the pooling estimated distribution can be compared to the sample. This ERplot is an updated version of that described in Hammond, A. (2019). Proposal of the 'extreme rank plot' for extreme value analysis: with an emphasis on flood frequency studies. Hydrology Research, 50 (6), 1495–1507.

Value

The extreme rank plot as described in the details

Author(s)

Anthony Hammond

Examples

```
#Get an AMAX sample and plot
AM.27083 <- GetAM(27083)
ERPlot(AM.27083$Flow)
#Get a pooled estimate of Lcv & LSkew to use with the GF argument
QuickResults(GetCDs(27083), gauged = TRUE)
#Use the resulting Lcv, Lskew and RP2 for the GF argument and change the title
ERPlot(AM.27083$Flow, main = "Site 27083 pooled comparison", GF = c(0.23, 0.17, 12))
```

EVPlot

Extreme value plot (frequency and growth curves)

Description

Plots the extreme value frequency curve or growth curve with observed sample points.

Usage

```
EVPlot(
    x,
    dist = "GenLog",
    scaled = TRUE,
    Title = "Extreme value plot",
    ylabel = NULL,
    LineName = NULL,
    Unc = TRUE
)
```

26

EVPlotAdd

Arguments

x	a numeric vector. The sample of interest
dist	a choice of distribution. "GEV", "GenLog", "Kappa3", "Gumbel" or "GenPareto". The default is "GenLog"
scaled	logical argument with a default of TRUE. If TRUE the plot is a growth curve (scaled by the QMED). If FALSE, the plot is a frequency curve
Title	a character string. The user chosen plot title. The default is "Extreme value plot"
ylabel	a character string. The user chosen label for the y axis. The default is "Q/QMED" if scaled = TRUE and "Discharge $(m3/s)$ " if scaled = FALSE
LineName	a character string. User chosen label for the plotted curve
Unc	logical argument with a default of TRUE. If TRUE, 95 percent uncertainty in- tervals are plotted.

Details

The plotting has the option of generalised extreme value (GEV), generalised Pareto (GenPareto), Gumbel, or generalised logistic (GenLog) distributions. The uncertainty is quantified by bootstrapping.

Value

An extreme value plot (frequency or growth curve) with intervals to quantify uncertainty

Author(s)

Anthony Hammond

Examples

#Get an AMAX sample and plot the growth curve with the GEV distribution
AM.203018 <- GetAM(203018)
EVPlot(AM.203018\$Flow, dist = "GEV")</pre>

EVPlotAdd

Add lines and/or points to an extreme value plot

Description

Functionality to add extra lines or points to an extreme value plot (derived from the EVPlot function).

Usage

```
EVPlotAdd(
  Pars,
  dist = "GenLog",
  Name = "Adjusted",
  MED = NULL,
  xyleg = NULL,
  col = "red",
  lty = 1,
  pts = NULL,
  ptSym = NULL
)
```

Arguments

Pars	a numeric vector of length two. The first is the Lcv (linear coefficient of variation) and the second is the Lskew (linear skewness).
dist	distribution name with a choice of "GenLog", "GEV", "GenPareto", "Kappa3", and "Gumbel"
Name	character string. User chosen name for points or line added (for the legend)
MED	The two year return level. Necessary In the case where the EV plot is not scaled
xyleg	a numeric vector of length two. They are the x and y position of the symbol and text to be added to the legend.
col	The colour of the points of line that have been added
lty	An integer. The type of line added
pts	A numeric vector. An annual maximum sample, for example. This is for points to be added
ptSym	An integer. The symbol of the points to be added

Details

A line can be added using the Lcv and Lskew based on one of four distributions (Generalised extreme value, Generalised logistic, Gumbel, Generalised Pareto). Points can be added as a numeric vector. If a single point is required, the base points() function can be used and the x axis will need to be log(RP-1).

Value

Additional, user specified line or points to an extreme value plot derived from the EVPlot function.

Author(s)

Anthony Hammond

28

EVPool

Examples

```
#Get an AMAX sample and plot the growth curve with the GEV distribution
AM.203018 <- GetAM(203018)
EVPlot(AM.203018$Flow, dist = "GEV")
#Now add a line (dotted & red) for the generalised logistic distribution
#first get the Lcv and Lskew using the LMoments function
pars <- as.numeric(LMoments(AM.203018[,2])[c(5,6)])
EVPlotAdd(Pars = pars, dist = "GenLog", Name = "GenLog", xyleg = c(-5.2,2.65), lty = 3)
#Now add a line for the gumbel distribution which is darkgreen and dashed.
EVPlotAdd(Pars = pars[1], dist = "Gumbel", Name = "Gumbel",
xyleg = c(-5.19,2.5), lty = 3, col = "darkgreen")
#now plot afresh and get another AMAX and add the points
EVPlot(AM.203018$Flow, dist = "GEV")
AM.27090 <- GetAM(27090)
EVPlotAdd(xyleg = c(-4.9,2.65), pts = AM.27090[,2], Name = "27090")
```

```
EVPool
```

Extreme value plot for pooling groups

Description

Plots the extreme value frequency curve or growth curve for gauged or ungauged pooled groups

Usage

```
EVPool(
    x,
    AMAX = NULL,
    gauged = FALSE,
    dist = "GenLog",
    QMED = NULL,
    Title = "Pooled growth curve",
    UrbAdj = FALSE,
    CDs
)
```

Arguments

х	pooling group derived from the Pool() function
AMAX	the AMAX sample to be plotted in the case of gauged. If NULL, & gauged equals TRUE, the AMAX from the first site in the pooling group is used
gauged	logical argument with a default of FALSE. If FALSE, the plot is the ungauged pooled curve accompanied by the single site curves of the group members. If TRUE, the plot is the gauged curve and single site curve with the observed points added
dist	a choice of distribution. Choices are "GEV", "GenLog", "Kappa3", or "Gumbel". The default is "GenLog"

QMED	a chosen QMED to convert the curve from a growth curve to the frequency curve
Title	a character string. The user chosen plot title. The default is "Pooled growth curve"
UrbAdj	a logical argument with a default of FALSE. If TRUE and urban adjustment is applied to the pooled growth curve
CDs	catchment descriptors derived from either GetCDs or CDsXML. Only necessary if UrbAdj is TRUE

Value

An extreme value plot for gauged or ungauged pooling groups

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form an ungauged pooling group and apply EVPlot.
CDs.28015 <- GetCDs(28015)
Pool.28015 <- Pool(CDs.28015, exclude = 28015)</pre>
EVPool(Pool.28015)
#Do the same for the gauged case, change the title, and convert with a QMED of 105.5.
PoolG.28015 <- Pool(CDs.28015)</pre>
EVPool(PoolG.28015, gauged = TRUE, Title = "Gauged frequency curve - Site 28015", QMED = 9.8)
#Pretend we have an extra AMAX for the gauge. Amend the pooling group Lcv and LSkew
#for the site accordingly then apply EVPool with the updated AMAX.
#Firstly, get the AMAX sample
AM.28015 <- GetAM(28015)
#Add an extra AMAX flow of 15m3/s
Append28015 <- append(AM.28015$Flow, 15)</pre>
#Amend the Lcv and Lskew in the pooling group
PoolG.28015[1, c(16, 17)] <- c(Lcv(Append28015), LSkew(Append28015))</pre>
#Now plot gauged with the updated AMAX
EVPool(PoolG.28015, AMAX = Append28015, gauged = TRUE)
```

FlowDurationCurve Flow duration curve

Description

A function to plot flow duration curves for a single flow series or flow duration curves from multiple flow series.

FlowDurationCurve

Usage

```
FlowDurationCurve(
  x = NULL,
  main = "Flow duration curve",
  CompareCurves = NULL,
  LegNames = NULL,
  Cols = NULL,
  AddQs = NULL,
  ReturnData = FALSE
)
```

Arguments

х	a dataframe with date in the first column and numeric (flow) in the second.
main	A title for the plot. The default is Flow duration curve.
CompareCurves	A user supplied list where each element is a numeric vector (each a flow series). This is useful for when you want to compare curves from multiple flow series'.
LegNames	User supplied names for the legend. This only works when the CompareCurves argument is used. The default is Curve1, Curve2CurveN.
Cols	User supplied vector of colours. This only works when the CompareCurves argument is used. The default is the Zissou 1 palette.
AddQs	The is to add additional flows and associated horizontal plot lines to the plot. It should be a single numeric value or a vector, for example $c(25, 75, 100)$.
ReturnData	Logical argument with a default of FALSE. When TRUE, a dataframe is re- turned with the data from the plot.

Details

The user can input a dataframe of dates (or POSIXct) and flow to return a plot of the flow duration curve for annual, winter and summer. Or a list of flow series' (vectors) can be applied for a plot comparing the individual flow duration curves

Value

If a dataframe of date in the first column and flow in the second is applied with the x argument a plot of a the flow duration curves for winter, summer and annual is returned. If a list of flow series is applied with the CompareCurves argument the associated flow duration curves are all plotted together. If ReturnData is TRUE, the plotted data is also returned.

Author(s)

Anthony Hammond

Examples

```
# Plot a flow duration curve for the Thames at Kingston Oct 2000 - Sep 2015.
FlowDurationCurve(ThamesPQ[,c(1,3)])
#Add a couple of extra flow lines for the plot
FlowDurationCurve(ThamesPQ[,c(1,3)], AddQs = c(25,200))
#Compare flows from the rather wet 2013 water year (rows 4749 and 5114) with the rest of the flow
FlowDurationCurve(CompareCurves = list(ThamesPQ$Q[-seq(4749,5114)],
ThamesPQ$Q[4749:5114]), LegNames = c("All but 2013","water year 2013"))
```

FlowSplit

Description

A function to separate baseflow from runoff.

Flow splitter

Usage

```
FlowSplit(
    x,
    BaseQUpper = NULL,
    AdjUp = NULL,
    ylab = "Value",
    xlab = "Time index"
)
```

Arguments

x	A numeric vector (your flow series / hydrograph).
BaseQUpper	Numeric value which is an upper level of baseflow (i.e. the baseflow will not extend above this level). The default is the mean of x. It can be set arbitrarily high so that the baseflow joins all low points/troughs in the hydrograph.
AdjUp	A numeric value between 0 and 0.5. This allows the user to adjust the base- flow up the falling limb/s of the hydrogaph. With 0.05 being a small upward adjustment and 0.49 being a large upward adjustment.
ylab	Label for the yaxis (character string). The default is "value",
xlab	Label for the xaxis (character string). The default is "Time index".

Details

The function is intended for the event scale as opposed to long term flow series. It works by linearly joining all the low points in the hydrograph - also the beginning and end points. Where a low point is any point with two higher points either side. Then any values above the hydrograph (xi) are set as xi. The baseflow point on the falling limb of the hydrograph/s can be raised using the AdjUp argument. The function works for any sampling frequency and arbitrary hydrograph length (although more suited for event scale and sub-annual events in general). This function is not design

32

GenLogAM

for deriving long term baseflow index. It could be used for such a purpose but careful consideration would be required for the BaseQUpper argument especially for comparison across river locations. If baseflow index is required the BFI function (with daily mean flow) is more suitable.

Value

A dataframe with the original flow (x) in the first column and the baseflow in the second. A plot of the original flow and the baseflow is also returned.

Author(s)

Anthony Hammond

Examples

```
# We'll extract a wet six month period on the Thames during the 2006–2007 hydrological year
ThamesQ <- subset(ThamesPQ[,c(1,3)], Date >= "2006-11-04" & Date <= "2007-05-06")
#Then apply the flow split with default settings
QSplit <- FlowSplit(ThamesQ$Q)</pre>
#Now do it with an upper baseflow level of 100m3/s
QSplit <- FlowSplit(ThamesQ$Q, BaseQUpper = 100)</pre>
# First we'll use the DesHydro function to pick out a reasonable looking event from the Thames flow.
Q <- DesHydro(ThamesPQ[,c(1,3)], Plot = FALSE, EventSep = 15)
Q <- Q$AllScaledHydrographs$hydro7
#Then we'll use our flow split function
FlowSplit(Q)
#Next we will get a single peaked "idealised" hydrograph using the ReFH function.
QReFH <- ReFH(GetCDs(15006))</pre>
QReFH <- QReFH[[2]]$TotalFlow
#Now use the function with and without an upward adjustment of the baseflow on the falling limb.
QFlowSplit <- FlowSplit(QReFH)</pre>
QFlowSplit <- FlowSplit(QReFH, AdjUp = 0.15)
```

```
GenLogAM
```

Generalised logistic distribution - estimates directly from sample

Description

Estimated quantiles as a function of return period (RP) and vice versa, directly from the data

Usage

GenLogAM(x, RP = 100, q = NULL)

Arguments

Х	numeric vector (block maxima sample)
RP	return period (default = 100)
q	quantile (magnitude of variable)

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. The parameters are estimated by the method of L-moments, as detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'.

Value

quantile as a function of RP or vice versa.

Author(s)

Anthony Hammond

Examples

```
#Get an annual maximum sample and estimate the 50-year RP
AM.27090 <- GetAM(27090)
GenLogAM(AM.27090$Flow, RP = 50)
#Estimate the RP for a 600m3/s discharge
GenLogAM(AM.27090$Flow, q = 600)
```

GenLogEst

Generalised logistic distribution estimates from parameters

Description

Estimated quantiles as function of return period (RP) and vice versa, from user input parameters

Usage

GenLogEst(loc, scale, shape, q = NULL, RP = 100)

Arguments

loc	location parameter
scale	scale parameter
shape	shape parameter
q	quantile. magnitude of the variable under consideration
RP	return period

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP.

34

GenLogGF

Value

quantile as a function of RP or vice versa

Author(s)

Anthony Hammond

Examples

```
#Get an annual maximum sample, estimate the parameters and estimate 50-year RP
AM.27090 <- GetAM(27090)
GenLogPars(AM.27090$Flow)
#Store parameters in an object
Pars <- as.numeric(GenLogPars(AM.27090$Flow))
#get estimate of 50-yr flow
GenLogEst(Pars[1], Pars[2], Pars[3], RP = 50)
#Estimate the RP for a 600m3/s discharge
GenLogEst(Pars[1], Pars[2], Pars[3], q = 600)
```

GenLogGF

Generalised logistic distribution growth factors

Description

Estimated growth factors as a function of return period, with inputs of Lcv & LSkew (linear coefficient of variation & linear skewness)

Usage

```
GenLogGF(lcv, lskew, RP)
```

Arguments

lcv	linear coefficient of variation
lskew	linear skewness
RP	return period

Details

Growth factors are calculated by the method outlined in the Flood Estimation Handbook, volume 3, 1999.

Value

Generalised logistic estimated growth factor

Author(s)

Anthony Hammond

Examples

#Estimate the 50-year growth factors from an Lcv and Lskew of 0.17 and 0.04, respectively. GenLogGF(0.17, 0.04, RP = 50)

GenLogPars

Generalised logistic distribution parameter estimates

Description

Estimated parameters from a sample (with Lmoments or maximum likelihood estimation) or from L1 (first L-moment), Lcv (linear coefficient of variation), and LSkew (linear skewness)

Usage

GenLogPars(x = NULL, mle = FALSE, L1, LCV, LSKEW)

Arguments

х	numeric vector. The sample
mle	logical argument with a default of FALSE. If FALSE the parameters are es- timated with Lmoments, if TRUE the parameters are estimated by maximum likelihood estimation.
L1	first Lmoment
LCV	linear coefficient of variation
LSKEW	linear skewness

Details

The L-moment estimated parameters are by the method detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'

Value

Parameter estimates (location, scale, shape)

Author(s)

Anthony Hammond
GenParetoEst

Examples

```
#Get an annual maximum sample and estimate the parameters using Lmoments
AM.27090 <- GetAM(27090)
GenLogPars(AM.27090$Flow)
#Estimate parameters using MLE
GenLogPars(AM.27090$Flow, mle = TRUE)
#calculate Lmoments and estimate the parmeters with L1, Lcv and Lskew
LMoments(AM.27090$Flow)
#store linear moments in an object
LPars <- as.numeric(LMoments(AM.27090$Flow))[c(1,5,6)]
GenLogPars(L1 = LPars[1], LCV = LPars[2], LSKEW = LPars[3])
```

GenParetoEst Generalised Pareto distribution estimates from parameters

Description

Estimated quantiles as function of return period (RP) and vice versa, from user input parameters

Usage

GenParetoEst(loc, scale, shape, q = NULL, RP = 100, ppy = 1)

Arguments

loc	location parameter
scale	scale parameter
shape	shape parameter
q	quantile. magnitude of the variable under consideration
RP	return period
рру	peaks per year. Default is one

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. The average number of peaks per year argument (ppy) is for the function to convert from the peaks over threshold (POT) scale to the annual scale. For example, if there are 3 peaks per year, the probability associated with the 100-yr return period estimate would be 0.01/3 (i.e. an RP of 300 on the POT scale) rather than 0.01.

Value

quantile as a function of RP or vice versa

Author(s)

Anthony Hammond

Examples

```
#Get a POT sample, estimate the parameters, and estimate 50-year RP
ThamesPOT <- POTextract(ThamesPQ[,c(1,3)], thresh = 0.90)
GenParetoPars(ThamesPOT$peak)
#Store parameters in an object
Pars <- as.numeric(GenParetoPars(ThamesPOT$peak))
#get estimate of 50-yr flow
GenParetoEst(Pars[1], Pars[2], Pars[3], ppy = 1.867, RP = 50)
#Estimate the RP for a 600m3/s discharge
GenParetoEst(Pars[1], Pars[2], Pars[3], ppy = 1.867, q = 600)
```

GenParetoGF

Generalised Pareto distribution growth factors

Description

Estimated growth factors as a function of return period, with inputs of Lcv & LSkew (linear coefficient of variation & linear skewness)

Usage

GenParetoGF(lcv, lskew, RP, ppy = 1)

Arguments

lcv	linear coefficient of variation
lskew	linear skewness
RP	return period
рру	peaks per year

Details

Growth factors (GF) are calculated by the method outlined in the Flood Estimation Handbook, volume 3, 1999. The average number of peaks per year argument (ppy) is for the function to convert from the peaks over threshold (POT) scale to the annual scale. For example, if there are 3 peaks per year, the probability associated with the 100-yr return period estimate would be 0.01/3 (i.e. an RP of 300 on the POT scale) rather than 0.01.

Value

Generalised Pareto estimated growth factor

Author(s)

Anthony Hammond

38

GenParetoPars

Examples

```
#Get POT flow data from the Thames at Kingston (noting the no. peaks per year).
#Then estimate the 100-year growth factor with lcv and lskew estimates
TPOT <- POTextract(ThamesPQ[,c(1,3)], thresh = 0.90)
GenParetoGF(Lcv(TPOT$peak), LSkew(TPOT$peak), RP = 100, ppy = 1.867)
#multiply by the median of the POT data for an estimate of the 100-yr flood
GenParetoGF(Lcv(TPOT$peak), LSkew(TPOT$peak), RP = 100, ppy = 1.867)*median(TPOT$peak)
```

GenParetoPars Generalised Pareto distribution parameter estimates

Description

Estimated parameters from a sample (with Lmoments or maximum likelihood estimation) or from L1 (first L-moment), Lcv (linear coefficient of variation), and LSkew (linear skewness)

Usage

GenParetoPars(x = NULL, mle = FALSE, L1, LCV, LSKEW)

Arguments

mlelogical argument with a default of FALSE. If FALSE the parameters are estimated with Lmoments, if TRUE the parameters are estimated by maximum likelihood estimationL1first LmomentLCVlinear coefficient of variationLSKEWlinear skewness	Х	numeric vector. The sample
LCV linear coefficient of variation	mle	timated with Lmoments, if TRUE the parameters are estimated by maximum
	L1	first Lmoment
LSKEW linear skewness	LCV	linear coefficient of variation
	LSKEW	linear skewness

Details

The L-moment estimated parameters are by the method detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'

Value

Parameter estimates (location, scale, shape)

Author(s)

Anthony Hammond

Examples

```
#Get a peaks over threshold sample and estimate the parameters using Lmoments
ThamesPOT <- ThamesPOT <- POTextract(ThamesPQ[,c(1,3)], thresh = 0.90)
GenParetoPars(ThamesPOT$peak)
#Estimate parameters using MLE
GenParetoPars(ThamesPOT$peak, mle = TRUE)
#calculate Lmoments and estimate the parmeters with L1, Lcv and Lskew
LMoments(ThamesPOT$peak)
#store linear moments in an object
LPars <- as.numeric(LMoments(ThamesPOT$peak))[c(1,5,6)]
GenParetoPars(L1 = LPars[1], LCV = LPars[2], LSKEW = LPars[3])
```

GenParetoPOT Generalised Pareto distribution - estimates directly from sample

Description

Estimated quantiles as function of return period (RP) and vice versa, directly from the data

Usage

GenParetoPOT(x, ppy = 1, RP = 100, q = NULL)

Arguments

х	numeric vector (block maxima sample)
рру	peaks per year
RP	return period (default = 100)
q	quantile (magnitude of variable)

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. The average number of peaks per year argument (ppy) is for the function to convert from the peaks over threshold (POT) scale to the annual scale. For example, if there are 3 peaks per year, the probability associated with the 100-yr return period estimate would be 0.01/3 (i.e. an RP of 300 on the POT scale) rather than 0.01. The parameters are estimated by the method of L-moments, as detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'.

Value

quantile as a function of RP or vice versa

Author(s)

Anthony Hammond

40

GetAM

Examples

```
#Get a POT series and estimate the 50-year RP
ThamesPOT <- POTextract(ThamesPQ[,c(1,3)], thresh = 0.90)
GenParetoPOT(ThamesPOT$peak, ppy = 1.867, RP = 50)
#Estimate the RP for a 600m3/s discharge
GenParetoPOT(ThamesPOT$peak, ppy = 1.867, q = 600)</pre>
```

GetAM	Get an annual maximum sample from the National River Flow Archive
	sites suitable for pooling

Description

Extracts the annual maximum peak flow sample and associated dates for the site of interest.

Usage

GetAM(ref)

Arguments

ref the site reference of interest (numeric)

Value

A data.frame with columns; Date, Flow, and id

Author(s)

Anthony Hammond

Examples

#Get an AMAX sample and display it in the console
GetAM(203018)
#Save an AMAX sample as an object
AM.203018 <- GetAM(203018)</pre>

GetCDs

Get catchment descriptors from the National River Flow Archive sites considered suitable for median annual maximum flow estimation (QMED) and pooling.

Description

Extracts the catchment descriptors for a site of interest from the National River Flow Archive. If the site is considered suitable for QMED and pooling the CDs are extracted from the QMEDData data.frame. Otherwise they are extracted using the NRFA API.

Usage

GetCDs(x)

Arguments

Х

t

the site reference of interest (numeric)

Value

A data.frame with columns; Descriptor and Value.

Author(s)

Anthony Hammond

Examples

#Get CDs and display in the console CDs.203018 <- GetCDs(203018) CDs.203018

GetDataEA_QH	Get flow or level data from the Environment Agency's Hydrology Data
	Explorer

Description

Function to extract flow or level data from the Environment Agency's Hydrology Data Explorer.

GetDataEA_QH

Usage

```
GetDataEA_QH(
  Lat = 54,
  Lon = -2.25,
  Range = 20,
  RiverName = NULL,
  WISKI_ID = NULL,
  From = NULL,
  To = NULL,
  Type = "flow",
  Period = "DailyMean"
)
```

Arguments

Lat	Latitude (as a decimal) for the centre of the search for gauges. You can convert BNG to Lat and Lon using the GridRefConvert function.
Lon	Longitude (as a decimal) for the centre of the search for gauges. You can convert BNG to Lat and Lon using the GridRefConvert function.
Range	Radius of search when using latitude and longitude inputs (km).
RiverName	Name of the river along which you want to search for gauges. Character string.
WISKI_ID	The WISKI ID for the gauge from which you want to obtain data (character string). Note that sometimes a preceding zero, which is not returned via the API, is needed. If the data extraction fails, this may be the cause and you can resolve it by including the preceding zero in the WISKI_ID.
From	Date for start of data extraction in the format of "2015-12-02". If NULL the start date of the available data is used.
То	Date for the end of data extraction in the format of "2015-12-02". If NULL end date of the available data is used.
Туре	The variable to extract, either "flow" or "level"
Period	The sampling rate of the data you want. Either "DailyMax", "DailyMean", "Hourly", "15Mins".

Details

To find gauges you can input either a river name or a latitude and longitude. You can convert BNG to Lat and Lon using the ConvertGridRef function (you can also get lat and lon by left clicking on google maps). The lat and lon option will provide all flow and level gauges within a specified range (default of 10km). This provides gauged details including the WISKI ID. You can get data from specific gauges using the WISKI_ID. Note that flow gauges also have level data available. You can get data from a date range using the From and To arguments or you can return all data by leaving the From and To as the default (NULL). Lastly, WISKI IDs are sometimes returned without a preceding 0 which might be necessary for the data extraction (oddly, most do have the necessary 0). If data extraction fails try adding a 0 to the beginning of the WISKI ID.

Value

If searching for gauge details with lat and lon or river name, then a list is returned. The first element is a dataframe with flow gauge details and the second is a dataframe of level gauge details. When extracting flow or level data with a WISKI ID then a dataframe with two columns is returned. The first being a Date or POSIXct column/vector and the second is the timeseries of interest.

Author(s)

Anthony Hammond

Examples

```
#Find gauges on the river Tame
## Not run: GetDataEA_QH(RiverName = "Tame")
#Find gauges within 10km of a latlon grid reference somewhere near the
#centre of Dartmoor
## Not run: GetDataEA_QH(Lat = 50.6, Lon = -3.9, Range = 10)
#Get all available daily maximum flow data from the Bellever gauge on the
#East Dart River.
## Not run: BelleverMax <- GetDataEA_QH(WISKI_ID = "SX67F051")
#Get 15-minute data from the Bellever for the Novermeber 2024 event
## Not run: BelleverNov2024 <- GetDataEA_QH(WISKI_ID = "SX67F051",
From = "2024-11-23", To = "2024-11-25", Period = "15Mins")
## End(Not run)</pre>
```

GetDataEA_Rain Get Environment Agency rainfall data (England).

Description

Extract rainfall data from the Environment Agency's Hydrology Data Explorer.

Usage

```
GetDataEA_Rain(
  Lat = 54,
  Lon = -2,
  Range = 10,
  WISKI_ID = NULL,
  Period = "Daily",
  From = NULL,
  To = NULL
)
```

44

Arguments

Lat	Latitude (as a decimal) for the centre of the search for gauges. You can convert BNG to Lat and Lon using the GridRefConvert function.
Lon	Longitude (as a decimal) for the centre of the search for gauges. You can convert BNG to Lat and Lon using the GridRefConvert function.
Range	The radius (km) from the point of interest (Lat, Lon) for which the user wants rain gauge information (currently it only seems to work to just over 20km).
WISKI_ID	The WISKI identification (as "character") for the rain gauge of interest
Period	The sampling rate of the rainfall in hours. Either "Daily", "15Mins", "Hourly".
From	The start date of the data extraction in the form of "YYYY-MM-DD". To get data from the first date available leave as NULL.
То	The end date of the data extraction in the form of "YYYY-MM-DD". To get data from the first date available leave as NULL.

Details

The function provides one of two outputs. Either information about available local rain gauges, or the data from a specified gauge (specified by WISKI ID). The process is to find the local information (including WISKI ID) by using the latitude and longitude and range (You can convert BNG to Lat and Lon using the GridRefConvert function). Then use the WISKI ID to get the data. If data requested is not available, for example - outside the date range or not available at the requested sampling rate, an error message is returned stating "no lines available in input". To extract all the available data leave the From and To arguments as Null.

Value

If searching for rain gauge details with the Latitude and Longitude a dataframe of gauges is returned. If extracting rainfall using the WISKI_ID, a dataframe is returned with Date / POSIXct in the first columns and rainfall in the second.

Author(s)

Anthony Hammond

```
#Get information about available rain gauges.
#within a 10km radius of Lat = 54.5, Lon = -3.2
## Not run: GetDataEA_Rain(Lat = 54.5, Lon = -3.2)
#Now we'll use the WISKI reference for the Honister rain gauge
# to get some hourly rain data for the Dec 2015
## Not run: HonisterDec2015 <- GetDataEA_Rain(WISKI_ID = "592463",
Period = "Hourly", From = "2015-12-01", To = "2015-12-31")
## End(Not run)
#Now we'll have a look at the top of the data and plot it
## Not run: head(HonisterDec2015)
## Not run: plot(HonisterDec2015, type = "h", ylab = "Rainfall (mm)")
```

GetDataMetOffice

Description

Extracts regional mean temperature or rainfall from the met office UK & regional series. The total duration of bright sunshine is also available.

Usage

GetDataMetOffice(Variable, Region)

Arguments

Variable	Either Tmean, Rainfall, or Sunshine
Region	One of "UK", "England", "Wales", "Scotland", "Northern_Ireland", "England_and_Wales", "England_N", "England_S", "Scotland_N", "Scotland_E", "Scotland_W", "Eng- land_E_and_NE", "England_NW_and_N_Wales", "Midlands", "East_Anglia", "England_SW_and_S_Wales", "England_SE_and_Central_S".

Details

The function returns time series data from the 19th century through to the present month.

Value

A data.frame with 18 columns; year, months, seasons, and annual. Rows then represent each year of the timeseries.

Author(s)

Anthony Hammond

```
#Get the Rainfall series for the UK
## Not run: UKRain <- GetDataMetOffice(Variable = "Rainfall", Region = "UK")
#Now we'll get mean temperature data for East Anglia
## Not run: TempEastAnglia <- GetDataMetOffice(Variable = "Tmean", Region = "East_Anglia")</pre>
```

GetDataNRFA

Description

Extracts NRFA data using the API.

Usage

GetDataNRFA(ID, Type = "Q")

Arguments

ID	ID number of the gauge of interest.
Туре	Type of data required. One of "Q", "P", "PQ", "Gaugings", "AMAX", "POT", or "Catalogue".

Details

The function can be used to get daily catchment rainfall or mean flow, or both together (concurrent). It can also be used to get gaugings, AMAX, and POT data. Note that some sites have rejected peak flow years. In which case, if Type = AMAX or POT, the function returns a list, the first element of which is the rejected years, the second is the full AMAX or POT. Lastly if Type = "Catalogue" it will return a dataframe of all the NRFA gauges, associated details, comments, and descriptors.

Value

A data.frame with date in the first columns and variable/s of interest in the remaining column/s. Except for the following circumstances: When Type = "Catalogue", then a large dataframe is returned with all the NRFA gauge metadata. When Type = "AMAX" or "POT" and there are rejected years a list is returned. Where the first element is the dataframe of data and the second is rejected year/s (character string).

Author(s)

Anthony Hammond

```
#Get the concurrent rainfall and mean flow series for the Tay at Ballathie (site 15006).
## Not run: BallathiePQ <- GetDataNRFA(15006, "PQ")
#Now we'll get the gaugings
## Not run: BallathieGaugings <- GetDataNRFA(15006, "Gaugings")</pre>
```

GetDataSEPA_QH

Description

Function to extract flow or level data from SEPA.

Usage

```
GetDataSEPA_QH(
  Lat = NULL,
  Lon = NULL,
  RiverName = NULL,
  Type = "Flow",
  StationID = NULL,
  Range = 20,
  From = NULL,
  To = NULL,
  Period = "Daily"
)
```

Arguments

Lat	Latitude (as a decimal) for the centre of the search for gauges. You can convert BNG to Lat and Lon using the GridRefConvert function.
Lon	Longitude (as a decimal) for the centre of the search for gauges. You can convert BNG to Lat and Lon using the GridRefConvert function.
RiverName	Name of the river along which you want to search for gauges. Character string.
Туре	The variable to extract, either "flow" or "level"
StationID	The ID for the gauge from which you want to obtain data (character string)
Range	Radius of search when using latitude and longitude inputs (km).
From	Date for start of data extraction in the format of "2015-12-02". If NULL the first date of the available data is used.
То	Date for the end of data extraction in the format of "2015-12-02". If NULL the present date is used (and most recent available data is returned).
Period	The sampling rate of the data you want. Either "Daily", "Hourly", or "15Mins".

Details

To find gauges you can input either a river name or a latitude and longitude. You can convert BNG to Lat and Lon using the ConvertGridRef function. The lat and lon option will provide all flow or level gauges within a specified range (default of 50km). This provides gauged details including the StationID. You can get data from specific gauges using the StationID. Note that flow gauges also have level data available. You can get data from a date range using the From and To arguments. If the From and To arguments are left as NULL the full range of available data are returned.

Value

If searching for gauge details with lat and lon or river name, then a dataframe is returned with necessary information to obtain flow or level data. When extracting flow or level data with a station ID then a dataframe with two columns is returned. The first being a Date or POSIXct column/vector and the second is the timeseries of interest.

Author(s)

Anthony Hammond

Examples

```
#Find gauges on the river Spey
## Not run: GetDataSEPA_QH(RiverName = "Spey")
#Find gauges within 20km of a latlon grid reference somewhere near the centre of Scotland
## Not run: GetDataSEPA_QH(lat = 56, lon = -4, Range = 20)
#Get all available daily mean flow data from the Boat o Brig gauge on the Spey
## Not run: SpeyDaily <- GetDataSEPA_QH(StationID = "37174")</pre>
#Get 15-minute data from the Boat o Brig for the highest recorded peak
## Not run: BoatOBrigAug1970 <- GetDataSEPA_QH(StationID = "37174",</pre>
From = "1970-08-16", To = "1970-08-19", Period = "15Mins")
## End(Not run)
```

GetDataSEPA_Rain	Get Scottish Environment Protection Agency (SEPA) hourly rainfall
	data.

Description

Extract hourly rainfall data from SEPA's API.

Usage

```
GetDataSEPA_Rain(
 Lat = NULL,
 Lon = NULL,
 Range = 30,
 StationName,
 From = NULL,
 To = NULL
)
```

Arguments

Lat	Latitude of the point of interest. Provided when the user wants information about available local rain gauges
Lon	Longitude of the point of interest. Provided when the user wants information about available local rain gauges

Range	The radius (km) from the point of interest (Lat, Lon) for which the user wants a list of rain gauges (default is 30).
StationName	The name of the station for which you want rainfall. If you type something other than one of the available stations, the list of stations will be returned.
From	A start date for the data in the form of "YYYY-MM-DD". Default of NULL means the earliest available date is used
То	An end date for the data in the form of "YYYY-MM-DD". The default is the most recent date available.

Details

You can download data using the gauge name and you can find gauges within a given range using the latitude and longitude. If the 'From' date is left as null, the earliest date of available data will be used. If the 'To' date is left as null, the most recent date of available data will be used.

Value

A data.frame with POSIXct in the first column, and rainfall in the second column. Unless the StationName provided is not in the available list, then the available list is returned.

Author(s)

Anthony Hammond

Examples

```
#Get the list of available stations
## Not run: GetDataSEPA_Rain(StationName = "AnythingButAStationName")
#Now we'll get rain from the Bannockburn station
## Not run: Bannockburn <- GetDataSEPA_Rain(StationName = "Bannockburn",
From = "1998-10-01", To = "1998-10-31")
## End(Not run)
#Now we'll have a look at the top of the data and plot it
## Not run: head(Bannockburn)
## Not run: plot(Bannockburn, type = "h", ylab = "Rainfall (mm)")
```

GetQMED

QMED from a gauged site suitable for QMED

Description

Provides QMED (median annual maximum flow) from a site suitable for QMED, using the site reference.

Usage

GetQMED(x)

GEVAM

Arguments

x the gauged reference

Value

the median annual maximum

Author(s)

Anthony Hammond

Examples

```
#Get the observed QMED from sites 55002
GetQMED(55002)
```

GEVAM	Generalised extreme value distribution - estimates directly from sam-
	ple

Description

Estimated quantiles as function of return period (RP) and vice versa, directly from the data

Usage

GEVAM(x, RP = 100, q = NULL)

Arguments

Х	numeric vector (block maxima sample)	
RP	return period (default = 100)	
q	quantile (magnitude of variable)	

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. The parameters are estimated by the method of L-moments, as detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'.

Value

quantile as a function of RP or vice versa.

Author(s)

Anthony Hammond

Examples

```
#Get an annual maximum sample and estimate the 50-year RP
AM.27090 <- GetAM(27090)
GEVAM(AM.27090$Flow, RP = 50)
#Estimate the RP for a 600m3/s discharge
GEVAM(AM.27090$Flow, q = 600)</pre>
```

GEVEst

Generalised extreme value distribution estimates from parameters

Description

Estimated quantiles as function of return period (RP) and vice versa, from user input parameters

Usage

GEVEst(loc, scale, shape, q = NULL, RP = 100)

Arguments

loc	location parameter
scale	scale parameter
shape	shape parameter
q	quantile. magnitude of the variable under consideration
RP	return period

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP.

Value

quantile as a function of RP or vice versa

Author(s)

Anthony Hammond

52

GEVGF

Examples

```
#Get an annual maximum sample, estimate the parameters and estimate 50-year RP
AM.27090 <- GetAM(27090)
GEVPars(AM.27090$Flow)
#Store parameters in an object
Pars <- as.numeric(GEVPars(AM.27090$Flow))
#get estimate of 50-yr flow
GEVEst(Pars[1], Pars[2], Pars[3], RP = 50)
#Estimate the RP for a 600m3/s discharge
GEVEst(Pars[1], Pars[2], Pars[3], q = 600)
```

GEVGF

Generalised extreme value distribution growth factors

Description

Estimated growth factors as a function of return period, with inputs of Lcv & LSkew (linear coefficient of variation & linear skewness)

Usage

GEVGF(lcv, lskew, RP)

Arguments

lcv	linear coefficient of variation	
lskew	linear skewness	
RP	return period	

Details

Growth factors are calculated by the method outlined in the Flood Estimation Handbook, volume 3, 1999.

Value

Generalised extreme value estimated growth factor

Author(s)

Anthony Hammond

```
#Estimate the 50-year growth factors from Lcv = 0.17 and Lskew = 0.04 GEVGF(0.17, 0.04, RP = 50)
```

GEVPars

Description

Estimated parameters from a sample (with Lmoments or maximum likelihood estimation) or from L1 (first L-moment), Lcv (linear coefficient of variation), and LSkew (linear skewness)

Usage

GEVPars(x = NULL, mle = FALSE, L1, LCV, LSKEW)

Arguments

х	numeric vector. The sample
mle	logical argument with a default of FALSE. If FALSE the parameters are es- timated with Lmoments, if TRUE the parameters are estimated by maximum likelihood estimation
L1	first Lmoment
LCV	linear coefficient of variation
LSKEW	linear skewness

Details

The L-moment estimated parameters are by the method detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'

Value

Parameter estimates (location, scale, shape)

Author(s)

Anthony Hammond

```
#Get an annual maximum sample and estimate the parameters using Lmoments
AM.27090 <- GetAM(27090)
GEVPars(AM.27090$Flow)
#Estimate parameters using MLE
GEVPars(AM.27090$Flow, mle = TRUE)
#calculate Lmoments and estimate the parmeters with L1, Lcv and Lskew
LMoments(AM.27090$Flow)
#store linear moments in an object
LPars <- as.numeric(LMoments(AM.27090$Flow))[c(1,5,6)]
GEVPars(L1 = LPars[1], LCV = LPars[2], LSKEW = LPars[3])
```

GoFCompare

Description

compares the RMSE of four distribution fits for a single AMAX sample.

Usage

GoFCompare(x)

Arguments

Х

a numeric vector (your AMAX sample)

Details

This function calculates an RMSE fit score for four distributions (GEV, GenLog, Gumbel, & Kappa3). The lowest RMSE is the best fit. It works as follows. For each distribution: Step1. Simulate 500 samples the same size as x. Step2. Calculate the mean across all 500 samples for each rank to create an ordered central estimate. Step3. Calculate the RMSE between the result of step 2 and the ordered x. Step4. Standardise the RMSE by dividing it by the mean of x and multiply it by 100 (RMSE as a percentage of mean). Note that this is not a hypothesis test. It is only for comparing the fit across the distributions.

Value

A list. The first element is a dataframe with four columns and one row of results. Each column has the standardised RMSE associated with one of the four distributions (GEV, GenLog, Gumbel, Kappa3). The second element is a character string stating the distribution with the best fit.

Author(s)

Anthony Hammond

```
# Get an AMAX sample then compare the fit..
AM15006 <- GetAM(15006)
GoFCompare(AM15006$Flow)
```

GoFComparePool

Description

compares the RMSE of four distribution fits for a pooling group.

Usage

GoFComparePool(x)

Arguments

Х

a numeric vector (your AMAX sample)

Details

This function calculates an RMSE fit score for four distributions (GEV, GenLog, Gumbel, & Kappa3). The lowest RMSE is the best fit. It works for pooling groups created using the Pool or PoolSmall function. It uses the same method as GoFCompare (see the associated details of that function). It first standardises the pooled AMAX samples (by dividing them by median) and then treats them as a single large sample. Note that this is not a hypothesis test. It is only for comparing the fit across the distributions.

Value

A list. The first element is a dataframe with four columns and one row of results. Each column has the standardised RMSE associated with one of the four distributions (GEV, GenLog, Gumbel, Kappa3). The second element is a character string stating the distribution with the best fit.

Author(s)

Anthony Hammond

```
# Get a pooling group then compare the fit..
Pool60009 <- Pool(GetCDs(60009))
GoFComparePool(Pool60009)</pre>
```

GumbelAM

Description

Estimated quantiles as a function of return period (RP) and vice versa, directly from the data

Usage

GumbelAM(x, RP = 100, q = NULL)

Arguments

x	numeric vector (block maxima sample)	
RP	return period (default = 100)	
q	quantile (magnitude of variable)	

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. The parameters are estimated by the method of L-moments, as detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'.

Value

quantile as a function of RP or vice versa.

Author(s)

Anthony Hammond

```
#Get an annual maximum sample and estimate the 50-year RP
AM.27090 <- GetAM(27090)
GumbelAM(AM.27090$Flow, RP = 50)
#Estimate the RP for a 600m3/s discharge
GumbelAM(AM.27090$Flow, q = 600)</pre>
```

GumbelEst

Description

Estimated quantiles as function of return period (RP) and vice versa, from user input parameters

Usage

GumbelEst(loc, scale, q = NULL, RP = 100)

Arguments

loc	location parameter
scale	scale parameter
q	quantile. magnitude of the variable under consideration
RP	return period

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP.

Value

quantile as a function of RP or vice versa

Author(s)

Anthony Hammond

```
#Get an annual maximum sample, estimate the parameters and estimate 50-year RP
AM.27090 <- GetAM(27090)
Pars <- as.numeric(GumbelPars(AM.27090$Flow))
GumbelEst(Pars[1], Pars[2], RP = 50)
#Estimate the RP for a 600m3/s discharge
GumbelEst(Pars[1], Pars[2], q = 600)</pre>
```

GumbelGF

Description

Estimated growth factors as a function of return period, with inputs of Lcv & LSkew (linear coefficient of variation & linear skewness)

Usage

GumbelGF(lcv, RP)

Arguments

lcv	linear coefficient of variation
RP	return period

Details

Growth factors are calculated by the method outlined in the Flood Estimation Handbook, volume 3, 1999.

Value

Gumbel estimated growth factor

Author(s)

Anthony Hammond

Examples

#Estimate the 50-year growth factors from an Lcv of 0.17. GumbelGF(0.17, RP = 50)

GumbelPars

Gumbel distribution parameter estimates

Description

Estimated parameters from a sample (with Lmoments or maximum likelihood estimation) or from L1 (first L-moment), Lcv (linear coefficient of variation)

Usage

GumbelPars(x = NULL, mle = FALSE, L1, LCV)

Arguments

x	numeric vector. The sample
mle	logical argument with a default of FALSE. If FALSE the parameters are es- timated with Lmoments, if TRUE the parameters are estimated by maximum likelihood estimation
L1	first Lmoment
LCV	linear coefficient of variation

Details

The L-moment estimated parameters are by the method detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'

Value

Parameter estimates (location, scale)

Author(s)

Anthony Hammond

Examples

```
#Get an annual maximum sample and estimate the parameters using Lmoments
AM.27090 <- GetAM(27090)
GumbelPars(AM.27090$Flow)
#Estimate parameters using MLE
GumbelPars(AM.27090$Flow, mle = TRUE)
#calculate Lmoments and estimate the parmeters with L1 and Lcv
Pars <- as.numeric(LMoments(AM.27090$Flow)[c(1,5)])
GumbelPars(L1 = Pars[1], LCV = Pars[2])</pre>
```

11	\mathbf{r}
п	2

Heterogeneity measure (H2) for pooling groups.

Description

Quantifies the heterogeneity of a pooled group

Usage

 $H_2(x, H_1 = FALSE)$

HydroPlot

Arguments

х	pooling group derived from the Pool() function
H1	logical with a default of FALSE. If TRUE, the function applies the 'H1' version of the test (see Hosking & Wallis 1997 reference). If FALSE, the default H2 version is applied.

Details

The H2 measure was developed by Hosking & Wallis and can be found in their book 'Regional Frequency Analysis: an approach based on LMoments (1997). It was also adopted for use by the Flood Estimation Handbook (1999) and is described in volume 3.

Value

A vector of two characters; the first representing the H2 score and the second stating a qualitative measure of heterogeneity.

Author(s)

Anthony Hammond

Examples

```
#Get CDs, form a pooling group and calculate H2
CDs.203018 <- GetCDs(203018)
Pool.203018 <- Pool(CDs.203018)
H2(Pool.203018)</pre>
```

HydroPlot

Hydrological plot of concurrent discharge and precipitation

Description

Plots concurrent precipitation and discharge with precipitation along the top and discharge along the bottom

Usage

```
HydroPlot(
    x,
    main = "Concurrent Rainfall & Discharge",
    ylab = "Discharge (m3/s)",
    From = NULL,
    To = NULL,
    adj.y = 1.5,
    plw = 1,
    qlw = 1.8,
    Return = FALSE
)
```

Arguments

x	a data.frame with three columns in the order of date (or POSIXct), precipitation, and discharge
main	a character string. The user chosen plot title. The default is "Concurrent Rainfall & Discharge"
ylab	User choice for the y label of the plot. THe default is "Discharge (m3/s)".
From	a starting time for the plot. In the form of a date or POSIXct object. The default is the first row of x
То	an end time for the plot. In the form of a date or POSIXct object. The default is the last row of x
adj.y	a numeric value to adjust the closeness of the preciptation and discharge in the plot. Default is 1.5. A lower value brings them closer and a larger value further apart
plw	a numeric value to adjust the width of the precipitation lines. Default is one. A larger value thickens them and vice versa
qlw	a numeric value to adjust the width of the discharge line. Default is 1.8. A larger value thickens them and vice versa
Return	a logical argument with a default of FALSE. If TRUE the data-frame of time, precipitation, and flow is returned

Details

The input of x is a dataframe with the first column being time. If the data is sub daily this should be class POSIXct with time as well as date.

Value

A plot of concurrent precipitation and discharge. With the former at the top and the latter at the bottom. If the Return argument equals true the associated data-frame is also returned.

Author(s)

Anthony Hammond

```
#Plot the Thames precipitation and discharge for the 2013 hydrological year,
#adjusting the y axis to 1.8.
HydroPlot(ThamesPQ, From = "2013-10-01", To = "2014-09-30", adj.y = 1.8)
```

КарраЗАМ

Description

Estimated quantiles as a function of return period (RP) and vice versa, directly from the data

Usage

Kappa3AM(x, RP = 100, q = NULL)

Arguments

Х	numeric vector (block maxima sample)
RP	return period (default = 100)
q	quantile (magnitude of variable)

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. The parameters are estimated by the method of L-moments, as detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'. The Kappa3 distribution is as defined by This is the Kappa3 distribution as defined in Kjeldsen, T (2019), 'The 3-parameter Kappa distribution as an alternative for use with FEH pooling groups.'Circulation - The Newsletter of the British Hydrological Society, no. 142.

Value

quantile as a function of RP or vice versa.

Author(s)

Anthony Hammond

```
#Get an annual maximum sample and estimate the 50-year RP
AM.27090 <- GetAM(27090)
Kappa3AM(AM.27090$Flow, RP = 50)
#Estimate the RP for a 600m3/s discharge
Kappa3AM(AM.27090$Flow, q = 600)</pre>
```

Kappa3Est

Description

Estimated quantiles as function of return period (RP) and vice versa, from user input parameters

Usage

Kappa3Est(loc, scale, shape, q = NULL, RP = 100)

Arguments

loc	location parameter
scale	scale parameter
shape	shape parameter
q	quantile. magnitude of the variable under consideration
RP	return period

Details

If the argument q is used, it overrides RP and provides RP as a function of q (magnitude of variable) as opposed to q as a function of RP. This is the Kappa3 distribution as defined in Kjeldsen, T (2019), 'The 3-parameter Kappa distribution as an alternative for use with FEH pooling groups.'Circulation - The Newsletter of the British Hydrological Society, no. 142.

Value

quantile as a function of RP or vice versa

Author(s)

Anthony Hammond

```
#Get an annual maximum sample, estimate the parameters and estimate 50-year RP
AM.27090 <- GetAM(27090)
#Get parameters and Store as an object
Pars <- as.numeric(Kappa3Pars(AM.27090$Flow))
#get estimate of 50-yr flow
Kappa3Est(Pars[1], Pars[2], Pars[3], RP = 50)
#Estimate the RP for a 600m3/s discharge
Kappa3Est(Pars[1], Pars[2], Pars[3], q = 600)</pre>
```

Kappa3GF

Description

Estimated growth factors as a function of return period, with inputs of Lcv & LSkew (linear coefficient of variation & linear skewness)

Usage

Kappa3GF(lcv, lskew, RP)

Arguments

lcv	linear coefficient of variation
lskew	linear skewness
RP	return period

Details

Growth factors are calculated by the method outlined in Kjeldsen, T (2019), 'The 3-parameter Kappa distribution as an alternative for use with FEH pooling groups.'Circulation - The Newsletter of the British Hydrological Society, no. 142

Value

Kappa3 distribution estimated growth factor

Author(s)

Anthony Hammond

```
#Get a ungauged pooled Lcv and LSkew for catchment 15006
PooledRes <- as.numeric(QuickResults(GetCDs(15006), plot = FALSE)[[2]])
#Calculate Kappa growth factor for the 100-year flood
Kappa3GF(PooledRes[1], PooledRes[2], RP = 100)</pre>
```

Kappa3Pars

Description

Estimated parameters from a sample (using Lmoments) or from user supplied L1 (first L-moment), Lcv (linear coefficient of variation), and LSkew (linear skewness)

Usage

Kappa3Pars(x = NULL, L1, LCV, LSKEW)

Arguments

х	numeric vector. The sample
L1	first Lmoment
LCV	linear coefficient of variation
LSKEW	linear skewness

Details

The L-moment estimated parameters are by the method detailed in 'Hosking J. Wallis J. 1997 Regional Frequency Analysis: An Approach Based on L-moments. Cambridge University Press, New York'. The Kappa3 distribution is as defined by This is the Kappa3 distribution as defined in Kjeldsen, T (2019), 'The 3-parameter Kappa distribution as an alternative for use with FEH pooling groups.'Circulation - The Newsletter of the British Hydrological Society, no. 142.

Value

Parameter estimates (location, scale, shape)

Author(s)

Anthony Hammond

```
#Get an annual maximum sample and estimate the parameters.
AM.27090 <- GetAM(27090)
Kappa3Pars(AM.27090$Flow)
#calculate Lmoments and estimate the parmeters with L1, L2, Lcv, and Lskew
LPars <- as.numeric(LMoments(AM.27090$Flow))[c(1,2,5,6)]
Kappa3Pars(L1 = LPars[1], LCV = LPars[2], LSKEW = LPars[3])
```

Lcv

Description

Calculates the Lcv from a sample of data

Usage

Lcv(x)

Arguments

х

a numeric vector. The sample of interest

Details

Lcv calculated according to methods outlined by Hosking & Wallis (1997): Regional Frequency Analysis and approach based on LMoments. Also in the Flood Estimation Handbook (1999), volume 3.

Value

Numeric. The Lcv of a sample.

Author(s)

Anthony Hammond

Examples

```
#Get an AMAX sample and calculate the Lmoments
AM.27051 <- GetAM(27051)
Lcv(AM.27051$Flow)</pre>
```

LcvUrb

Urban adjustment for the linear coefficient of variation (Lcv)

Description

Urbanises or de-urbanises the Lcv using the methods outlined in the guidance by Wallingford HydroSolutions: 'WINFAP 4 Urban Adjustment Procedures'

Usage

LcvUrb(lcv, URBEXT2000, DeUrb = FALSE)

LKurt

Arguments

lcv	the Lcv (numeric)
URBEXT2000	quantiication of urban and suburbanisation for the subject catchment
DeUrb	logical argument with a default of FALSE. If set to TRUE, de-urbanisation ad- justment is performed, if FALSE, urbanisation adjustment is performed

Details

The method for de-urbanisation isn't explicitly provided in 'WINFAP 4 Urban Adjustment Procedures', but the procedure is a re-arrangment of the urbanisation equation, solving for Lcv rather than Lcv-urban.

Value

The urban adjust Lcv or the de-urbanised Lcv

Author(s)

Anthony Hammond

Examples

```
#Choose an urban site (site 53006) from the NRFA data then apply a de-urban
#adjustment using the Lcv and URBEXT2000 displayed
NRFAData[which(rownames(NRFAData) == 53006),]
LcvUrb(0.21, 0.1138, DeUrb = TRUE)
#Get the pooled Lmoment ratios results for catchment 53006 and apply the
#urban adjustment using the pooled Lcv, and the URBEXT2000 for site 53006.
CDs.53006 <- GetCDs(53006)
QuickResults(CDs.53006)[[2]]
LcvUrb(0.196, 0.1138)
```

LKurt

Linear Kurtosis (LKurt)

Description

Calculates the LKurtosis from a sample of data

Usage

LKurt(x)

Arguments

Х

a numeric vector. The sample of interest

LMoments

Details

LKurtosis calculated according to methods outlined by Hosking & Wallis (1997): Regional Frequency Analysis and approach based on LMoments. Also in the Flood Estimation Handbook (1999), volume 3.

Value

Numeric. The LSkew of a sample.

Author(s)

Anthony Hammond

Examples

```
#Get an AMAX sample and calculate the Lmoments
AM.27051 <- GetAM(27051)
LKurt(AM.27051$Flow)</pre>
```

LMoments

Lmoments & Lmoment ratios

Description

Calculates the Lmoments and Lmoment ratios from a sample of data

Usage

LMoments(x)

Arguments

Х

a numeric vector. The sample of interest

Details

Lmoments calculated according to methods outlined by Hosking & Wallis (1997): Regional Frequency Analysis and approach based on LMoments. Also in the Flood Estimation Handbook (1999), volume 3.

Value

A data.frame with one row and column headings; L1, L2, L3, L4, Lcv, LSkew, and LKurt. The first four are the Lmoments and the next three are the Lmoment ratios.

Author(s)

Anthony Hammond

Examples

```
#Get an AMAX sample and calculate the Lmoments
AM.27051 <- GetAM(27051)
LMoments(AM.27051$Flow)
```

LRatioChange

Adjust L-Ratios in a pooling group

Description

Adjusts the linear coefficient of variation (Lcv) and the linear skewness (LSkew) for a chosen site in a pooling group

Usage

LRatioChange(x, SiteID, lcv, lskew)

Arguments

х	pooling group derived with the Pool function
SiteID	the identification number of the site in the pooling group that is to be changed (character or integer)
lcv	The user supplied Lcv. numeric
lskew	The user supplied LSkew. numeric

Details

Pooling groups are formed from the NRFAData data.frame and all the Lcv and LSkew values are precalculated using the National River Flow Archive Peak flow dataset noted in the description file. The resulting pooled growth curve is calculated using the Lcv and Lskew in the pooled group. The user may have further data and be able to add further peak flows to the annual maximum samples within a pooling group. If that is the case a new Lcv and Lskew can be determined using the LMoments function. These new values can be added to the pooling group with this LRatioChange function. Also the permeable adjustment function may have been applied to a site, which provides a new Lcv and LSkew. In which case, the LRatioChange function can be applied. The function creates a new pooling group object and x will still exist in it's original state after the function is applied.

Value

A new pooling group, the same as x except for the user adjusted Lcv and Lskew for the user selected site.

Author(s)

Anthony Hammond

70

LSkew

Examples

```
# Get some catchment descriptors and create a pooling group.
CDs.39001 <- GetCDs(39001)
Pool.39001 <- Pool(CDs.39001, iug = TRUE)
# apply the function to create a new adjusted pooling group,
#changing the subject site lcv and lskew to 0.187 and 0.164, respectively
Pool.39001Adj <- LRatioChange(Pool.39001, SiteID = 39001, lcv = 0.187, lskew = 0.164)</pre>
```

LSkew

Linear Skewness (LSkew)

Description

Calculates the LSkew from a sample of data

Usage

LSkew(x)

Arguments

х

a numeric vector. The sample of interest

Details

LSkew calculated according to methods outlined by Hosking & Wallis (1997): Regional Frequency Analysis and approach based on LMoments. Also in the Flood Estimation Handbook (1999), volume 3.

Value

Numeric. The LSkew of a sample.

Author(s)

Anthony Hammond

```
#Get an AMAX sample and calculate the Lmoments
AM.27051 <- GetAM(27051)
LSkew(AM.27051$Flow)</pre>
```

```
LSkewUrb
```

Description

Urbanises or de-urbanises the LSkew using the methods outlined in the guidance by Wallingford HydroSolutions: 'WINFAP 4 Urban Adjustment Procedures'

Usage

LSkewUrb(lskew, URBEXT2000, DeUrb = FALSE)

Arguments

lskew	the LSkew (numeric)
URBEXT2000	quantiication of urban and suburbanisation for the subject site
DeUrb	logical argument with a default of FALSE. If set to TRUE, de-urbanisation ad- justment is performed, if FALSE, urbanisation adjustment is performed

Details

The method for de-urbanisation isn't explicitly provided in 'WINFAP 4 Urban Adjustment Procedures', but the procedure is a re-arrangment of the urbanisation equation, solving for LSkew rather than LSkew-urban.

Value

The urban adjust Lcv or the de-urbanised Lcv

Author(s)

Anthony Hammond

```
#Choose an urban site (site 53006) from the NRFA data then apply a de-urban
#adjustment using the Lcv and URBEXT2000 displayed
NRFAData[which(rownames(NRFAData) == 53006),]
LSkewUrb(0.124, 0.1138, DeUrb = TRUE)
#Get the pooled Lmoment ratios results for catchment 53006 and apply the urban
#Get the CDS & adjustment using the pooled LSkew, and the URBEXT2000 for site 53006.
CDs.53006 <- GetCDs(53006)
QuickResults(CDs.53006)[[2]]
LSkewUrb(0.194, 0.1138)
```
MonthlyStats

Description

Derives monthly statistics from a data.frame with Dates or POSIXct in the first column and variable of interest in the second

Usage

```
MonthlyStats(
    x,
    Stat,
    AggStat = NULL,
    TS = FALSE,
    Plot = FALSE,
    ylab = "Magnitude",
    main = "Monthly Statistics",
    col = "grey"
)
```

Arguments

x	a data.frame with Dates or POSIXct in the first column and numeric vector in the second.
Stat	A user chosen function to calculate the statistic of interest; mean or sum for example. Could be a user developed function.
AggStat	the aggregating statistic. The default is mean. The function applied must have an na.rm argument (base R stat functions such as mean, max, and sum all have an na.rm argument.).
TS	A logical statement with a default of FALSE. If TRUE, instead of a dataframe of monthly statistics and average statistics, a monthly time series is returned.
Plot	logical argument with a default of FALSE. If TRUE the monthly statistics are plotted.
ylab	A label for the y axis of the plot. The default is "Magnitude"
main	A title for the plot. The default is "Monthly Statistics"
col	A choice of colour for the bar plot. A single colour or a vector (a colour for each bar).

Details

The statistic of interest for each month is calculated for each calendar year in the data.frame. An aggregated result is also calculated for each month using an aggregating statistic (the mean by default). The data.frame is first truncated at the first occurrence of January 1st and last occurrence of December 31st.

Value

A list with two elements. The first element is a data.frame with year in the first column and months in the next 12 (i.e. each row has the monthly stats for the year). The second element is a dataframe with month in the first column and the associated aggregated statistic in the second. i.e. the aggregated statistic (default is the mean) for each month is provided. However, of TS = TRUE, a monthly time series is returned - as a dataframe with date in the first column and monthly value in the second.

Author(s)

Anthony Hammond

Examples

```
# Get the mean flows for each month for the Thames at Kingston
QMonThames <- MonthlyStats(ThamesPQ[,c(1,3)], Stat = mean,
ylab = "Discharge (m3/s)", main = "Thames at Kingston monthly mean flow", Plot = TRUE)
# Get the monthly sums of rainfall for the Thames at Kingston
PMonThames <- MonthlyStats(ThamesPQ[,c(1,2)], Stat = sum,
ylab = "Rainfall (mm)", main = "Thames as Kingston monthly rainfall", Plot = TRUE)
```

NGRDist

British national grid reference (NGR) distances

Description

Calculates the euclidean distance between two british national grid reference points using the pythagorean method

Usage

NGRDist(i, j)

Arguments

i	a numeric vector of length two. The first being the easting and the second being the northing of the first site
j	a numeric vector of length two. The first being the easting and the second being the northing of the second site

Details

Note, that the result is converted to km when six digits are used for easting and northing, when six digits would usually provide a result in metres.

Value

A distance in kilometres (if six digits for easting and northing are used)

NonFloodAdj

Author(s)

Anthony Hammond

Examples

```
#Calculate the distance between the catchment centroid for the
#Kingston upon Thames river gauge and the catchment centroid for the
#gauge at Ardlethen on the River Ythan. First view the eastings and northings
GetCDs(10001)
GetCDs(39001)
NGRDist(i = c(381355, 839183), j = c(462899, 187850))
```

NonFloodAdj Non-flood adjustment

Description

Adjusts the linear coefficient of variation (Lcv) and the linear skewness to account for non-flood years

Usage

NonFloodAdj(x)

Arguments

Х

The annual maximum sample. Numeric vector

Details

The method is the "permeable adjustment method" detailed in chapter 19, volume three of the Flood Estimation Handbook, 1999. The method makes no difference for sites where there are no annual maximums (AM) in the sample that are < median(AM)/2. Once applied the results can be used with the LRatioChange function to update the associated member of a pooling group. There is also the NonFloodAdjPool() function which can be used for multiple sites in a pooling group.

Value

A list is returned. The first element of the list is a dataframe with one row and two columns. Lcv in the first column and Lskew in the second. The second element of the list is another dataframe with one row and three columns. Number of non-flood years in the first column, sample size in the second and the percent of non-flood year in the third.

Author(s)

Anthony Hammond

Examples

```
# Get an anuual maximum sample with a BFIHOST above 0.65 and with some
# annual maximums lower than median(AM)/2. And then apply the function.
NonFloodAdj(GetAM(44013)[,2])
```

NonFloodAdjPool Non-flood adjustment for pooling groups

Description

Applies the NonFloodAdj function to adjust the LCV and LSKEW of one or more sites in a pooling group.

Usage

```
NonFloodAdjPool(x, Index = NULL, AutoP = NULL, ReturnStats = FALSE)
```

Arguments

х	A pooling group, derived from the Pool() or PoolSmall() functions.
Index	An vector of indices (row numbers) of sites to be adjusted. If Index = NULL (the default) the function is applied to all sites.
AutoP	A percentage (numeric) of non flood years. Any sites in the group exceeding this value will be adjusted. This is an automated approach so that the user doesn't need to specify Index. If no sites are above AutoP, the function is applied to all sites.
ReturnStats	Logical with a default of FALSE. If set to TRUE, a dataframe of non-flood year stats is returned (see 'Value' section below) instead of the adjusted Pooling group.

Details

For more details of the method for individual sites see the details section of the NonFloodAdj function. As a default this function applies NonFloodAdj to every member of the pooling group. Index can be supplied which is the row name/s of the members you wish to adjust. Or AutoP can be applied and is a percentage. Any member with a greater percentage of non-flood years than AutoP is then adjusted.

Value

By default the pooling group is returned with adjusted LCVs and LSKEWs for all sites indexed (or all sites when Index = NULL), or all sites with percentage of non-flood years above AutoP. No difference will be seen for sites with no AMAX < 0.5QMED. If ReturnStats is set to TRUE, a dataframe with Non-flood year stats is returned. The dataframe has a row for each site in the pooling group and three columns. The forst the number of non-flood years, the second is the number of years, and the third is the associated percentage.

NRFAData

Author(s)

Anthony Hammond

Examples

```
# Set up a pooling group for site 44013. Then apply the function.
Pool44013 <- Pool(GetCDs(44013))
PoolNF <- NonFloodAdjPool(Pool44013)
#return the non flood stats for the pooling group
NonFloodAdjPool(Pool44013, ReturnStats = TRUE)</pre>
```

NRFAData	National River Flow Archive descriptors and calculated statistics for
	sites suitable for pooling

Description

A data.frame of catchment descriptors, Lmoments, Lmoment ratios, sample size and median annual maximum flow (QMED). NRFA Peak Flow Dataset - Version 13.0.2.

Usage

NRFAData

Format

A data frame with 543 rows and 27 variables

Details

The functions for pooling group formation and estimation rely on this dataframe. However, the data frame is open for manipulation in case the user wishes to add sites that aren't included, or change parts where local knowledge has improved on the data. Although, usually, in the latter case, such changes will be more appropriately applied to the formed pooling group. If changes are made, they will only remain within the workspace. If a new workspace is opened and the UKFE package is loaded, the data frame will have returned to it's original state.

Source

https://nrfa.ceh.ac.uk/peak-flow-dataset

OptimPars

Description

Estimates the parameters of the Generalised extreme value, generalised logistic, Kappa3, or Gumbel distribution from known return period estimates

Usage

OptimPars(x, dist = "GenLog")

Arguments

х	a data.frame with RPs in the first column and associated estimates in the second column
dist	a choice of distribution for the estimates. The choices are "GenLog", "GEV", "Kappa3", or "Gumbel" - the generalised logistic, generalised extreme value, Kappa3, and Gumbel distribution, respectively. The default is "GenLog"

Details

Given a dataframe with return periods (RPs) in the first column and associated estimates in the second column, this function provides an estimate of the distribution parameters. Ideally the first RP should be 2. Extrapolation outside the RPs used for calibration comes with greater uncertainty.

Value

The parameters of one of four user chosen distributions; Generalised logistic, generalised extreme value, Gumbel, and Kappa3.

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors and some quick results. Then estmate the GenLog parameters
Results <- QuickResults(GetCDs(27051), plot = FALSE)[[1]]
OptimPars(Results[,1:2])
```

Pool

Description

Function to develop a pooling group based on catchment descriptors

Usage

```
Pool(
  CDs = NULL,
  AREA,
  SAAR,
  FARL,
  FPEXT,
  N = 500,
  exclude = NULL,
  iug = FALSE,
  UrbMax = 0.03,
  DeUrb = FALSE
```

Arguments

)

CDs	catchment descriptors derived from either GetCDs or CDsXML
AREA	catchment area in km2
SAAR	catchment standard average annual rainfall (1961-1990) in mm
FARL	catchment flood attenuation from reservoirs & lakes
FPEXT	catchment floodplain extent. The proportion of the catchment that is estimated to be inundated by a 100-year flood
Ν	minimum Number of total gauged record years for the pooling group
exclude	sites to exclude from the pooling group. Either a single site reference or a vector of site references (numeric)
iug	iug stands for 'include urban gauge' - which refers to a gauged subject site if it's > UrbMax. It's a logical argument with default of FALSE. TRUE will over-ride the default and add the closest site in catchment descriptor space (should be the gauge of interest) to the pooling group if it has URBEXT2000 >= UrbMax
UrbMax	Maximum URBEXT2000 level with a default of 0.03. Any catchment with URBEXT2000 above this level will be excluded from the pooling group
DeUrb	logical argument with a default of FALSE. If true, the Lcv and LSkew of any site in the pooling group with URBEXT2000 > 0.03 will be de-urbanised

Details

A pooling group is created from a CDs object, derived from GetCDs or CDsXML, or specifically with the catchment descriptors (see arguments). To change the default pooling group, one or more sites can be excluded using the 'exclude' option, which requires either a site reference or multiple site references in a vector. If this is done, the site with the next lowest similarity distance measure is added to the group (until the total number of years is at least N). Sites with URBEXT2000 (urban extent) > 0.03 are excluded by default and this can be adjusted with UrbMax. If a gauged assessment is required and the site of interest is > UrbMax it can be included by setting iug = TRUE. Deurbanise the Lcv and Lskew (L-moment ratios) for sites with URBEXT2000 > UrbMax by setting DeUrb = TRUE. If the user has more data available for a particular site within the pooling group, the Lcv and Lskew for the site can be updated after the group has been finalised. An example of doing so is provided below. The pooling method is outlined in Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation.

Value

A data.frame of the pooling group with site reference row names and 24 columns, each providing catchment & gauge details for the sites in the pooling group.

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors
CDs.73005 <- GetCDs(73005)
#Set up a pooling group object called Pool.73005 excluding sites 79005 & 71011.
#Then print the group to the console
Pool.73005 <- Pool(CDs.73005, exclude = c(79005, 71011))
Pool.73005
#Form a pooling group, called PoolGroup, with the catchment descriptors specifically
PoolGroup <- Pool(AREA = 1000, SAAR = 800, FARL = 1, FPEXT = 0.01)
#Form a pooling group using an urban catchment which is intended for enhanced
#single site estimation - by including it in the group.
CDs.39001 <- GetCDs(39001)
Pool.39001 <- Pool(CDs.39001, iug = TRUE, DeUrb = TRUE)
#Change the Lcv and LSkew of the top site in the pooling group to 0.19 & 0.18,
#respectively.
PoolUpdate <- LRatioChange(Pool.39001, SiteID = 39001, 0.19, 0.18)</pre>
```

PoolEst

Pooled flood estimates

Description

Provides pooled results from a pooling group - gauged, ungauged and with urban adjustment if necessary.

PoolEst

Usage

```
PoolEst(
    x,
    gauged = FALSE,
    QMED,
    dist = "GenLog",
    RP = c(2, 5, 10, 20, 50, 75, 100, 200, 500, 1000),
    UrbAdj = FALSE,
    CDs = NULL,
    URBEXT = NULL,
    fseQMED = 1.46
)
```

Arguments

х	pooling group derived from the Pool function
gauged	logical argument with a default of FALSE. TRUE for gauged results and FALSE for ungauged
QMED	estimate of the median annual maximum flow
dist	a choice of distribution for the estimates. The choices are "GenLog", "GEV", "Kappa3", or "Gumbel"; the generalised logistic, generalised extreme value, Kappa3, and Gumbel distribution, respectively. The default is "GenLog"
RP	return period of interest. By default the following RPs are provided: 2, 5, 10, 20, 50, 75, 100, 200, 500, 1000
UrbAdj	logical argument with a default of FALSE. When TRUE, an urban adjustment is applied to the pooled Lcv and LSkew
CDs	catchment descriptors derived from either GetCDs or CDsXML
URBEXT	the catchment URBEXT2000, to be supplied if UrbAdj is TRUE and if CDs have not been
fseQMED	factorial standard error of the median annual maximum (QMED) estimate, used for quantifying ungauged uncertainty. Default is 1.46

Details

PoolEst is a function to provide results from a pooling group derived using the Pool function. QMED (median annual maximum flow) needs to be supplied and can be derived from the QMED function for ungauged estimates or the annual maximum sample for gauged estimates. If the catchment of interest is urban, the UrbAdj argument can be set to TRUE. If this is done, either URBEXT (urban extent) needs to be provided or the catchment descriptors, derived from CDsXML or GetCDs. The methods for estimating pooled growth curves are according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation. The methods for estimating the L-moments and growth factors are outlined in the Flood Estimation Handbook (1999), volume 3. The methods for quantifying uncertainty are detailed in Hammond, A. (2022). Easy methods for quantifying the uncertainty of FEH pooling analysis. Circulation - The Newsletter of the British Hydrological Society (152). When UrbAdj = TRUE, urban adjustment is applied to the QMED estimate according to the method outlined in the guidance by Wallingford HydroSolutions: 'WINFAP 4 Urban Adjustment Procedures'.

If RP is default then a list of length 4. Element one is a data frame with columns; return period (a range from 2 - 1000), peak flow estimates (Q), growth factor estimates (GF), lower and upper intervals of uncertainty (68 percent intervals for ungauged and 95 percent for gauged). The second element is the estimated Lcv and Lskew. The third provides distribution parameters for the growth curve. The fourth provides distribution parameters for the frequency curve. If RP is not the default only the first two elements are returned.

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors and form a pooling group. It's urban and
#therefore the site of interest is not included.
CDs.27083 <- GetCDs(27083)
Pool.27083 <- Pool(CDs.27083)
#Get results for the ungauged case, with urban adjustment
PoolEst(Pool.27083, QMED = 12, UrbAdj = TRUE, CDs = CDs.27083)
#Form the group again with the urban gauge included & undertake a gauged estimate
#with urban adjustment. QMED in this example is estimated as the median of the annual
#maximum series for site 27083.
PoolG.27083 <- PoolG.27083 <- Pool(CDs.27083, iug = TRUE, DeUrb = TRUE)
PoolEst(PoolG.27083, QMED = 12.5, UrbAdj = TRUE, CDs = CDs.27083)
```

PoolSmall

Create pooling group for small catchments

Description

Function to develop a small catchments pooling group based on catchment descriptors

Usage

```
PoolSmall(
  CDs = NULL,
  AREA,
  SAAR,
  N = 500,
  exclude = NULL,
  iug = FALSE,
  UrbMax = 0.03,
  DeUrb = FALSE
)
```

82

Value

PoolSmall

Arguments

CDs	catchment descriptors derived from either GetCDs or CDsXML
AREA	catchment area in km2
SAAR	catchment standard average annual rainfall (1961-1990) in mm
Ν	minimum Number of total gauged record years for the pooling group
exclude	sites to exclude from the pooling group. Either a single site reference or a vector of site references (numeric)
iug	iug stands for 'include urban gauge' - which refers to a gauged subject site if it's > UrbMax. It's a logical argument with default of FALSE. TRUE will over-ride the default and add the closest site in catchment descriptor space (should be the gauge of interest) to the pooling group if it has URBEXT2000 >= UrbMax
UrbMax	Maximum URBEXT2000 level with a default of 0.03. Any catchment with URBEXT2000 above this level will be excluded from the pooling group
DeUrb	logical argument with a default of FALSE. If true, the Lcv and LSkew of any site in the pooling group with URBEXT2000 > 0.03 will be de-urbanised

Details

A pooling group is created from a CDs object, derived from GetCDs or CDsXML, or specifically with the necessary catchment descriptors (see arguments). To change the default pooling group one or more sites can be excluded using the 'exclude' option, which requires either a site reference or multiple site references in a vector. If this is done, the site with the next lowest similarity distance measure is added to the group (until the total number of years is at least N). Sites with URBEXT2000 (urban extent) > 0.03 are excluded by default and this can be adjusted with the UrbMax argument. If a gauged assessment is required and the site of interest is > UrbMax it can be included by setting iug = TRUE. De-urbanise the Lcv and Lskew (L-moment ratios) of sites with URBEXT2000 > 0.03 by setting DeUrb = TRUE. If the user has more data available for a particular site within the pooling group, the Lcv and Lskew for the site can be updated after the group has been finalised.

Value

A data.frame of the pooling group with site reference row names and 24 columns, each providing catchment & gauge details for the sites in the pooling group.

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors
CDs.21001 <- GetCDs(21001)
#Set up a pooling group object called Pool.21001 excluding site 206006
#Then print the group to the console
Pool.21001 <- PoolSmall(CDs.21001, exclude = 206006)
Pool.21001
```

```
#Form a pooling group, called PoolGroup, with the catchment descriptors specifically
PoolGroup <- PoolSmall(AREA = 22, SAAR = 1702)</pre>
```

POTextract

Peaks over threshold (POT) data extraction

Description

Extracts independent peaks over a threshold from a sample

Usage

```
POTextract(
    x,
    div = NULL,
    TimeDiv = NULL,
    thresh = 0.975,
    Plot = TRUE,
    ylab = "Magnitude",
    xlab = "Time",
    main = "Peaks over threshold"
)
```

Arguments

х	either a numeric vector or dataframe with date (or POSIXct) in the first column and hydrological variable in the second
div	numeric percentile (between 0 and thresh), either side of which two peaks over the threshold are considered independent. Default is the mean of the sample.
TimeDi∨	Number of timesteps to define independence (supplements the div argument). As a default this is NULL and only 'div' defines independence. Currently this is only applicable for data.frames.
thresh	user chosen threshold. Default is 0.975
Plot	logical argument with a default of TRUE. When TRUE, the full hydrograph with the peaks over the threshold highlighted is plotted
ylab	Label for the plot yaxis. Default is "Magnitude"
xlab	Label (character) for the plot x axis. Default is "Time".
main	Title for the plot. Default is "Peaks over threshold"

Details

If the x argument is a numeric vector, the peaks will be extracted with no time information. x can instead be a data.frame with dates in the first column and the numeric vector in the second. In this latter case, the peaks will be time-stamped and a hydrograph, including POT, will be plotted by default. The method of extracting independent peaks assumes that there is a value either side of

POTt

which, events can be considered independent. For example, if two peaks above the chosen threshold are separated by the mean flow, they could be considered independent, but not if flow hasn't returned to the mean at any time between the peaks. Mean flow may not always be appropriate, in which case the 'div' argument can be applied (and is a percentile). The TimeDiv argument can also be applied to ensure the peaks are separated by a number of time-steps either side of the peaks. For extracting POT rainfall a div of zero could be used and TimeDiv can be used for further separation - which would be necessary for sub-daily time-series. In which case, with hourly data for example, TimeDiv could be set to 120 to ensure each peak is separated by five days either side as well as at least one hour with 0 rainfall. When plotted, the blue line is the threshold, and the green line is the independence line (div).

Value

Prints the number of peaks per year and returns a data.frame with columns; Date and peak, with the option of a plot. Or a numeric vector of peaks is returned if only a numeric vector of the hydrological variable is input.

Author(s)

Anthony Hammond

Examples

```
#Extract POT data from Thames mean daily flow 2000-10-01 to 2015-09-30 with
#div = mean and threshold = 0.95. Then display the first six rows
ThamesQPOT <- POTextract(ThamesPQ[, c(1,3)], thresh = 0.9)
head(ThamesQPOT)
#Extract Thames POT from only the numeric vector of flows and display the
#first six rows
ThamesQPOT <- POTextract(ThamesPQ[, 3], thresh = 0.9)
head(ThamesQPOT)
#Extract the Thames POT precipitation with a div of 0, the default
#threshold, and 5 timesteps (days) either side of the peak. Then display the first six rows
ThamesPPOT <- POTextract(ThamesPQ[, c(1,2)], div = 0, TimeDiv = 5)
head(ThamesPPOT)
```

POTt

Peaks over threshold (POT) data extraction (quick)

Description

Extracts independent peaks over a threshold from a sample, using time as the independence criteria.

Usage

```
POTt(
    x,
    threshold = 0.975,
    div,
```

```
Plot = TRUE,
PlotType = "l",
main = "Peaks over threhsold",
ylab = "Magnitude",
xlab = "Time"
```

Arguments

х	either a numeric vector or dataframe with date (or POSIXct) in the first column and hydrological variable in the second
threshold	user chosen threshold. Default is 0.975
div	number of time steps between peaks to ensure independence.
Plot	logical argument with a default of TRUE. When TRUE, the full hydrograph with the peaks over the threshold highlighted is plotted
PlotType	Type of plot with a default of "l" for line graph. For rainfall type "h" for bars could be used.
main	Title for the plot. Default is "Peaks over threshold"
ylab	Label (character) for the plot y axis. Default is "Magnitude"
xlab	Label (character) for the plot x axis. Default is "Time".

Details

This provides a quicker option than the POTextract function - useful for very long time series'. It only has the option of time division to ensure independence between peaks. If the x argument is a numeric vector, the peaks will be extracted with no time information. x can instead be a data.frame with dates in the first column and the numeric vector in the second. In this latter case, the peaks will be time-stamped and a hydrograph, including POT, will be plotted by default.

Value

A data.frame with columns; Date and peak, with the option of a plot. Or a numeric vector of peaks is returned if only a numeric vector of the variable is input as x.

Author(s)

Anthony Hammond

Examples

#Extract POT data from Thames catchment daily rainfall 2000-10-01 to 2015-09-30 with #div = 14 (14 days) and threshold = 0.975. Then display the first six rows ThamesPPOT <- POTt(ThamesPQ[, c(1,2)], div = 14) head(ThamesPPOT) #Extract Thames rainfall POT from only the numeric vector of rainfall, with threshold #set to 0.95 and div set to 14. Then display the first six rows ThamesPPOT <- POTt(ThamesPQ[, 2], threshold = 0.95, div = 14) head(ThamesPPOT)

QMED

Description

Estimated median annual maximum flow from catchment descriptors and donor sites

Usage

```
QMED(
 CDs = NULL,
 Don1 = NULL,
 Don2 = NULL,
 UrbAdj = FALSE,
 uef = FALSE,
 DonUrbAdj = FALSE,
 AREA,
  SAAR,
 FARL,
 BFIHOST,
 URBEXT2000 = NULL,
 Easting = NULL,
 Northing = NULL
```

Arguments

)

CDs	catchment descriptors derived from either GetCDs or CDsXML
Don1	numeric site reference for the a single donor (for donor candidates see DonAdj function)
Don2	vector of two site references for two donors (for donor candidates see DonAdj function)
UrbAdj	logical argument with a default of FALSE. True applies an urban adjustment
uef	logical argument with a default of FALSE. If true an urban expansion factor is applied to the URBEXT2000 value - using the current year.
DonUrbAdj	logical argument with a default of FALSE. If TRUE, an urban adjustement is applied to the donor/s QMEDcds estimate.
AREA	catchment area in km2
SAAR	standard average annual rainfall (mm)
FARL	flood attenuation from reservoirs and lakes
BFIHOST	baseflow index calculated from the catchment hydrology of soil type classifica- tion
URBEXT2000	measure of catchment urbanisation
Easting	Easting. A six digit Easting (British national grid reference).
Northing	Northing. A six digit Northing (British national grid reference).

Details

QMED is estimated from catchment descriptors: QMED = 8.3062*AREA^0.8510 0.1536^(1000/SAAR) FARL^3.4451 0.0460^(BFIHOST^2) as derived in Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation. The single donor method is from the same paper. The method for two donors is outlined in 'Kjeldsen, T. (2019). Adjustment of QMED in ungauged catchments using two donor sites. Circulation - The Newsletter of the British Hydrological Society, 4'. When UrbAdj = TRUE, urban adjustment is applied to the QMED estimate according to the method outlined in the guidance by Wallingford HydroSolutions: 'WINFAP 4 Urban Adjustment Procedures'. Urban donors should be avoided, but in the case that an urban donor is considered appropriate the QMEDcd estimate of the donor (or donors) can be urban adjusted by setting the DonUrbAdj argument to TRUE. For flexibility there is the option to input the relevant catchment descriptors directly rather than a CDs object.

Value

An estimate of QMED from catchment descriptors. If two donors are used the associated weights are also returned

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors and calculate QMED as if it was ungauged, with
#no donors, one donor, and two donors
CDs.55004 <- GetCDs(55004)
QMED(CDs.55004, Don1 = 55012)
QMED(CDs.55004, Don2 = c(55012, 60007))
#Get CDs for urban gauge and calculate QMED with urban adjustment
CDs.27083 <- GetCDs(27083)
QMED(CDs.27083, UrbAdj = TRUE)
```

QMEDData

National River Flow Archive descriptors and calculated statistics for sites suitable for QMED & pooling

Description

A data.frame of catchment & data descriptors relating to the median annual maximum flow (QMED). NRFA Peak Flow Dataset - Version 13.0.2

Usage

QMEDData

QMEDDonEq

Format

A data frame with 897 rows and 26 variables

Details

The functions for QMED estimation and retrieval of catchment descriptors rely on this dataframe. However, the data frame is open for manipulation in case the user wishes to add sites that aren't included, or change parts where local knowledge has improved on the data. If changes are made, they will only remain within the workspace. If a new workspace is opened and the UKFE package is loaded, the data frame will have returned to it's original state.

Source

https://nrfa.ceh.ac.uk/peak-flow-dataset

QMEDDonEq

QMED donor adjustment

Description

Applies a donor adjustment to the median annual maximum flow (QMED) estimate

Usage

QMEDDonEq(AREA, SAAR, FARL, BFIHOST, QMEDgObs, QMEDgCds, xSI, ySI, xDon, yDon, alpha = TRUE

)

Arguments

AREA	catchment area in km2
SAAR	standardised average annual rainfall in mm
FARL	flood attenuation from reservoirs and lakes
BFIHOST	the baseflow index as a function of soil type
QMEDgObs	the observed QMED at the donor site

QMEDgCds	the QMED equation derived QMED at the donor site
xSI	the catchment centroid easting for the site of interest
ySI	the catchment centroid northing for the site of interest
xDon	the catchment centroid easting for the donor site
yDon	the catchment centroid northing for the donor site
alpha	a logical argument with a default of TRUE. When FALSE the exponent in the donor equation is set to one. Otherwise it is determined by the distance between the donor and the subject site

Details

Although a single donor adjustment can be applied with the DonAdj() function and the QMED(), this is provided for flexibility. The method is that of Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation (2008).

Author(s)

Anthony Hammond

Examples

```
#Get observed QMED for site 15006
Qob <- median(GetAM(15006)[,2])
#Get QMED equation estimated QMED for the donor site
QCD <- QMED(CDs = GetCDs(15006))
#display CDs for site 27051 & note the easting and northing
GetCDs(27051)
#display CDs for site 15006 & note the easting and northing
GetCDs(15006)
#Apply the QMEDDonEq function with the information gained
QMEDDonEq(194, 1096, 0.955, 0.297, Qob, QCD, xSI = 289289,ySI = 947523,xDon = 280908,yDon = 953653)
```

```
QMEDfseSS
```

QMED factorial standard error for gauged sites

Description

Estimates the median annual maximum flow (QMED) factorial standard error (FSE) by bootstrapping the sample

Usage

QMEDfseSS(x)

Arguments

Х

a numeric vector. The sample of interest

QMEDLink

Details

The bootstrapping procedure resamples from the sample N*500 times with replacement. After splitting into 500 samples of size N, the median is calculated for each. Then the exponent of the standard deviation of the log transformed residuals is taken as the FSE. i.e. $\exp(sd(\log(x)-\max(\log(x)))))$, where x is the bootstrapped medians.

Value

The factorial standard error for the median of a sample.

Author(s)

Anthony Hammond

Examples

```
#Extract an AMAX sample and estimate the QMED factorial standard error
AM.203018 <- GetAM(203018)
QMEDfseSS(AM.203018$Flow)
```

QMEDLink

QMED Linking equation

Description

Estimates the median annual maximum flow (QMED) from non-flood flows

Usage

QMEDLink(Q5dmf, Q10dmf, DPSBAR, BFI)

Arguments

Q5dmf	numeric. The daily mean flow that is exceeded 5 percent of the time
Q10dmf	numeric. The daily mean flow that is exceeded 10 percent of the time
DPSBAR	a catchment descriptor. The average drainage path slope of the catchment
BFI	the baseflow index of the gauged flow

Details

The QMED Linking equation estimates QMED as a function of the flow that is exceeded five percent of the time, the flow that is exceeded 10 percent of the time, the baseflow index, and the catchment desciptor; drainage path slope (DPSBAR). All of these can be found for sites on the National River Flow Archive (NRFA) website. The method is provided in the guidance note 'WINFAP 4 QMED Linking equation' (2016) by Wallingford HydroSolutions.

Author(s)

Anthony Hammond

Examples

#Calculate the QMED for site 1001 (Wick at Tarroul)
QMEDLink(10.14, 7.352, 29.90, 0.39)

QMEDPOT

Empirical estimate of QMED from peaks over threshold (POT) data

Description

Estimates the median annual maximum flow (QMED) from peaks over threshold data

Usage

QMEDPOT(x, ppy)

Arguments

х	numerical vector. POT data
рру	number of peaks per year in the POT data

Details

If there are multiple peaks per year, the peaks per year (ppy) argument is used to convert to the annual scale to derive QMED. If ppy is one, then the median of the POT sample is returned (the median of x).

Author(s)

Anthony Hammond

Examples

```
#Extract some POT data and estimate QMED
ThamesPOT <- POTextract(ThamesPQ[,c(1,3)], thresh = 0.90)
QMEDPOT(ThamesPOT$peak, ppy = 1.867263)</pre>
```

QuickResults

Description

Provides pooled gauged, ungauged, or fake ungauged results, directly from the catchment descriptors

Usage

```
QuickResults(
  CDs,
  gauged = FALSE,
  dons = 2,
  Qmed = NULL,
  FUngauged = FALSE,
  plot = TRUE,
  dist = "GenLog"
)
```

Arguments

CDs	catchment descriptors derived from either GetCDs or CDsXML
gauged	logical argument with a default of FALSE. TRUE for gauged results and FALSE for ungauged
dons	number of donors required with a choice of 0, 1, or 2
Qmed	user supplied QMED which overrides the default QMED estimate
FUngauged	logical argument with a default of FALSE. TRUE provides an ungauged estimate whilst excluding the gauged site (the site with the most similar CDs)
plot	logical argument with a default of TRUE. TRUE provides an extreme value plot. FALSE prevents the plot
dist	a choice of distribution for the estimates. The choices are "GenLog", "GEV", "Kappa3", or "Gumbel; the generalised logistic, generalised extreme value, Kappa3, and Gumbel distributions, respectively. The default is "GenLog"

Details

The quick results function provides results with a default pooling group. If gauged = FALSE the median annual maximum flood (QMED) is estimated from catchment descriptors using the QMED equation and then adjusted with two of the closest un-urban gauged sites (can be changed to 0 or 1 donors). If the site is urban, an urban adjustment is made to the QMED and to the pooled growth curve. If gauged = TRUE QMED is the median of the gauged annual maxima and the growth curve is formed with the gauged weighting procedure (often known as enhanced single site). If the gauged catchment is urban, it's included in the pooling group and deurbanised before an urban adjustment is made to the final growth curve. If FUngauged = TRUE, the top site in the pooling group is

excluded and the estimate is performed henceforth in the manner of gauged = FALSE. If the CDs are from a gauged site that is not in the list of sites that are considered suitable for pooling, it won't be included in the pooling group. In which case, if gauged = TRUE, the result will be erroneous.

Value

A list of length two. Element one is a data frame with columns; return period (RP), peak flow estimates (Q) and growth factor estimates (GF). Two additional columns quantify the uncertainty. The second element is the estimated Lcv and Lskew (linear coefficient of variation and skewness). By default an extreme value plot is also returned

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors
CDs.73005 <- GetCDs(73005)
#Get default ungauged results
QuickResults(CDs.73005)
#Get gauged results with a GEV distribution
QuickResults(CDs.73005, gauged = TRUE, dist = "GEV")
#Get fake ungauged results with one donor
QuickResults(CDs.73005, FUngauged = TRUE, dons = 1)
```

Rating

Stage-Discharge equation optimisation

Description

Optimises a power law rating equation from observed discharge and stage

Usage

Rating(x, a = NULL)

Arguments

х	a data.frame with discharge in the first column and stage in the second
а	a user defined stage correction

ReFH

Details

The power law rating equation optimised here has the form $q = c(h+a)^n$; where 'q' is flow, 'h' is the stage, c' and 'n' are constants, and 'a' is the stage when flow is zero. The optimisation uses all the data provided in the dataframe (x). If separate rating limbs are necessary, x can be subset per limb. i.e. the rating function would be used multiple times, once for each subset of x. There is the option, with the 'a' argument, to hold the stage correction parameter (a), at a user defined level. If 'a' is NULL it will be calibrated with 'c' & 'n' as part of the optimisation procedure.

Value

A list with three elements. The first is a vetor of the three calibrated rating parameters. The second is the rating equation; discharge as a function of stage. The third is the rating equation; stage as a function of discharge. A rating plot is also returned.

Author(s)

Anthony Hammond

Examples

```
# Make up Some data:
Q <- c(177.685, 240.898, 221.954, 205.55, 383.051, 154.061, 216.582)
Stage <- c(1.855, 2.109, 2.037, 1.972, 2.574, 1.748, 2.016)
Observations <- data.frame(Q, Stage)
#apply the rating function:
Rating(Observations)
#Hold the stage correction at zero
Rating(Observations, a = 0)
```

ReFH

Revitalised Flood Hydrograph Model (ReFH)

Description

Provides outputs of the ReFH model from catchment descriptors or user defined inputs

Usage

```
ReFH(
  CDs = NULL,
  Depth = NULL,
  duration = NULL,
  timestep = NULL,
  scaled = NULL,
  PlotTitle = NULL,
  RPa = NULL,
  alpha = TRUE,
  season = NULL,
```

```
AREA = NULL,
TP = NULL,
BR = NULL,
BL = NULL,
Cmax = NULL,
Cini = NULL,
BFini = NULL,
Rain = NULL
```

Arguments

)

CDs	catchment descriptors derived from either GetCDs or ImportCD
Depth	a numeric value. The depth of rainfall used as input in the estimation of a design hydrograph. The default, when Depth = NULL, is a two year rainfall.
duration	a numeric value. A duration (hrs) for the design rainfall
timestep	a numeric value. A user defined data interval. The default changes depending on the estimated time to peak to formulate a sensible looking result
scaled	a numeric value of peak flow in m3/s
PlotTitle	a character string. A user defined title for the ReFH plot
RPa	return period for alpha adjustment. This is only for the purposes of the alpha adjustment, it doesn't change the rainfall input
alpha	a logical argument with default TRUE. If TRUE the alpha adjustment is applied based on RPa. If FALSE, no alpha adjustment is made
season	a choice of "summer" or "winter". The default is "summer" in urban catchments (URBEXT2000 > 0.03) and "winter" in rural catchments
AREA	numeric. Catchment area in km2.
TP	numeric. Time to peak parameter (hours)
BR	numeric. Baseflow recharge parameter
BL	numeric. Baseflow lag parameter (hours)
Cmax	numeric. Maximum soil moisture capacity parameter (mm)
Cini	numeric. Initial soil moisture content (mm)
BFini	numeric. Initial baseflow (m3/s)
Rain	numeric. User input rainfall (hourly). A numeric vector

Details

The ReFH is described in the Flood Estimation Handbook Supplementary Report No.1 (2007). The method to derive design rainfall profiles is described in the Flood Estimation Handbook (1999), volume 2. Users can also input their own rainfall with the 'Rain' argument. As a default, when catchment descriptors (CDs) are provided the ReFH function uses catchment descriptors to estimate the parameters of the ReFH model and the two year rainfall for the critical duration. The latter is based on a quadratic interpolation of the catchment descriptors RMED1H, RMED1D, and RMED2D (then a seasonal correction factor is applied). Parameters and initial conditions can also

SCF

be individually input by the user. If a parameter argument is used for one or more of the parameters, then these overwrite the CD derived parameters. If a value for the scaled argument is provided (m3/s), a scaled hydrograph is returned. The RPa argument doesn't change the rainfall input and is only needed for the alpha adjustment (see the FEH supplement report no.1).

Value

A list with two elements, and a plot. First element of the list is a data.frame of parameters, initial conditions and the catchment area. The second is a data.frame with columns Rain, NetRain, Runoff, Baseflow, and TotalFlow. If the scale argument is used a numeric vector containing the scaled hydrograph is returned instead of the results dataframe. The plot is of the ReFH output, with rainfall, net-rainfall, baseflow, runoff and total flow. If the scaled argument is used, a scaled hydrograph is plotted.

Author(s)

Anthony Hammond

Examples

```
#Get CDs and apply the ReFH function
CDs.203018 <- GetCDs(203018)
ReFH(CDs.203018)
#Apply the ReFH function, scale to a 100-year flow estimate and change the plot title accordingly
ReFH(CDs.203018, scaled = 182, PlotTitle = "100-Year Design Hydrograph - Site 203018")
#Apply the ReFH function with a user defined initial baseflow
ReFH(CDs.203018, BFini = 6)
```

SCF

Seasonal correction factor (SCF)

Description

The results of applying the ratio of the seasonal annual maximum rainfall for a given duration to the annual maximum rainfall for the same duration

Usage

SCF(SAAR, duration)

Arguments

SAAR	standardised average annual rainfall. Numeric
duration	duration in hours. Numeric

Details

The SCF and it's use is detailed in R&D Technical Report FD1913/TR - Revitalisation of the FSR/FEH rainfall runoff method (2005). The ReFH model has a design rainfall profile included for winter and summer but the depth duration frequency (DDF) model is calibrated on annual maximum peaks as opposed to seasonal peaks. The SCF is necessary to convert the DDF estimate to a seasonal one. Similarly, the DDF model is calibrated on point rainfall and the area reduction factor converts it to a catchment rainfall for use with a rainfall runoff model such as ReFH (see details of the ReFH function).The final depth, therefore is; Depth = DDFdepth x ARF x SCF.

Value

A data.frame of one row and two columns: SCFSummer and SCFWinter.

Author(s)

Anthony Hammond

Examples

#Derive the SCFs for a SAAR of 1981 and a duration of 6.5 SCF(1981, 6.5)

SimData	Data simulator	
---------	----------------	--

Description

Simulation of a random sample from the generalised extreme value, generalised logistic, Gumbel, Kappa3, or generalised Pareto distributions

Usage

SimData(n, pars = NULL, dist = "GenLog", GF = NULL)

Arguments

n	sample size to be simulated
pars	vector of parameters in the order of location, scale, shape (only location and shape for Gumbel)
dist	choice of distribution. Either "GEV", "GenLog", "Gumbel", "Kappa3", or "Gen-Pareto"
GF	vector of GF inputs in the order of Lcv, LSkew, QMED (only Lcv and QMED if dist = "Gumbel")

ThamesPQ

Details

The simulated sample can be generated using distribution parameters, or the growth factor (GF) inputs; linear coefficient of variationn (Lcv), linear skewness (LSkew) & the median annual maximum (QMED).

Value

A random sample of size n for the chosen distribution.

Author(s)

Anthony Hammond

Examples

```
#Simulate a sample of size 30 using parameters GenLog and parameters 299, 51, -0.042
SimData(30, pars = c(299, 51, -0.042), dist = "GenLog")
#Now simulate using the Lcv, Lskew, and median (0.17, 0.04, 310)
SimData(30, GF = c(0.17, 0.04, 310), dist = "GenLog")
```

ThamesPQ	Kingston upon Thames daily flow and catchment precipitation 2000-
	10-01 to 2015-09-30

Description

A data.frame of four columns; Date, Precipitation (P), & daily mean flow (Q)

Usage

ThamesPQ

Format

A data frame with 5478 rows and 4 columns:

Date Date

- **P** Precipitation, in mm
- Q Daily mean discharge, in m3/s

Source

https://nrfa.ceh.ac.uk/data/station/meanflow/39001

TrendTest

Description

A hypothesis test for trend

Usage

TrendTest(x, method = "mk", alternative = "two.sided")

Arguments

x	a numeric vector or a data.frame with dates in the first column and chronologi- cally ordered variable in the second.
method	a choice of test method. Choices are "mk" (Mann Kendall - the default), "pearson", and "spearman".
alternative	the alternative hypothesis. Options are "less", "greater", and "two.sided". The default is "two.sided".

Details

The test can be performed on a numeric vector, or a data.frame with dates in the first column and the associated variable of interest in the second. A choice can be made between Mann Kendall, Pearson, or Spearman tests. The Spearman and Mann Kendall are based on ranks and will therefore have the same results whether dates are included or not. The default is Mann Kendall. The default is to test for any trend (alternative = "two.sided"). For positive trend set alternative to "greater", and to test for negative trend set alternative to "less".

Interpretation: When testing for positive trend (alternative = "greater") the P_value is the probability of exceeding the observed statistic under the null hypothesis (that it is less than zero). The vice versa is true when testing for negative trend (alternative = "less"). For alternative = "two.sided" the P_value is the probability of exceeding the absolute value of the observed statistic under the null hypothesis (that it is different from zero). Low P values indicate that the null hypothesis is less likely.

Value

A data.frame with columns and associated values: P_value, statistic (Kendall's tau, Spearman's rho, or Pearson's correlation coefficient), and a standardised distribution value. The latter is either the z score (for MK test) or students 't' of the observed statistic under the null hypothesis.

Author(s)

Anthony Hammond

$U\!AF$

Examples

```
#Get AMAX sample and apply a trend test with the default Mann Kendall test.
AM.27083 <- GetAM(27083)
TrendTest(AM.27083)
#Apply the test with the pearson method with dates included and not
TrendTest(AM.27083, method = "pearson")
TrendTest(AM.27083$Flow, method = "pearson")
#Apply the default mk test for positive trend
TrendTest(AM.27083$Flow, alternative = "greater")
```

UAF

Urban adjustment factor (UAF) and percentage runoff urban adjustment factor (PRUAF)

Description

UAF and PRUAF from catchment descriptors for QMED estimation in ungauged urban catchments

Usage

UAF(CDs = NULL, URBEXT2000, BFIHOST)

Arguments

CDs	catchment descriptors derived from either GetCDs or CDsXML
URBEXT2000	quantification of catchment urbanisation (used when CDs is not)
BFIHOST	baseflow index as a function of hydrological soil type of the catchment (used when CDs is not)

Value

a data.frame with columns UAF and PRUAF

Author(s)

Anthony Hammond

Examples

```
#Get some catchment descriptors for an urban catchment calculate the UAF & PRUAF
CDs.53006 <- GetCDs(53006)
UAF(CDs.53006)
#Calculate UAF and PRUAF using a user input URBEXT2000 and BFIHOST
UAF(URBEXT2000 = 0.1138, BFIHOST = 0.3620)
```

Urban expansion factor

Description

This function provides a coefficient to multiply by URBEXT2000 to adjust it to a given year

Usage

UEF(Year)

Arguments

Year

The year for consideration. Numeric

Details

The urban expansion factor is detailed in Bayliss, A. Black, K. Fava-Verde, A. Kjeldsen, T. (2006). URBEXT2000 - A new FEH catchment descriptor: Calculation, dissemination and application. R&D Technical Report FD1919/TR, DEFRA, CEH Wallingford

Value

A numeric urban expansion factor.

Author(s)

Anthony Hammond

Examples

Get an expansion factor for the year 2023 UEF(2023)

UKOutline

UK outline

Description

Easting and northing national grid reference points around the coast of the UK

Usage

UKOutline

UEF

Uncertainty

Format

A data frame with 3867 rows and 2 variables

X_BNG Easting, British national grid reference

Y_BNG Northing, British national grid reference

Source

https://environment.data.gov.uk/

Uncertainty

Uncertainty quantification for gauged and ungauged pooled estimates

Description

Quantification of uncertainty for pooling results for the gauged and ungauged case

Usage

```
Uncertainty(
    x,
    Gauged = FALSE,
    qmed = NULL,
    Dist = "GenLog",
    Conf = 0.95,
    fseQMED = 1.55,
    UrbAdj = FALSE,
    URBEXT = NULL,
    Plot = TRUE,
    IncAMest = TRUE,
    Parametric = TRUE
)
```

Arguments

x	the pooled group derived from the Pool() or PoolSmall function
Gauged	a logical argument with a default of FALSE. If FALSE the uncertainty intervals are calculated for the ungauged case. If TRUE they are calculated for the gauged case
qmed	the QMED estimate for the ungauged case. It is derived from the observed AMAX if Gauged equals TRUE.
Dist	a choice of distribution to use for the estimates. Choices are "GEV", "GenLog", "Gumbel", or "Kappa3". The default is "GenLog"
Conf	the confidence level of the uncertainty intervals. Default is 0.95. Must be be- tween 0 and 1.

fseQMED	The factorial standard error of the QMED estimate for an ungauged assessment. The default is 1.55.
UrbAdj	applies an urban adjustment to the growth curves
URBEXT	URBEXT value for the site of interest. This is necessary if a UrbAdj equals TRUE.
Plot	logical argument with a default of TRUE. If TRUE a return level plot with results and margin of error is plotted. If FALSE, it is not.
IncAMest	logical argument with a default of TRUE. Sometimes when doing gauged (enhanced single site analysis), the central estimate of the single site estimate is outside the intervals of the ESS estimate. When this argument is true the confidence interval is expanded to include the central estimate for the single site. If FALSE, it is not.
Parametric	logical argument with a default of TRUE. If TRUE, the bootsrapping is done by simulation with the distribution of choice. If FALSE the bootsrapping is done by resampling with replacement.

Details

Uncertainty for both the gauged (enhanced single site) and ungauged case are quantified according to the bootstrapping procedures, which account for weights in the pooling group, detailed in Hammond, A. (2021). Sampling uncertainty of UK design flood estimation. Hydrology Research. 1357-1371. 52 (6).

Value

A dataframe with 10 rows and four columns. Return period in the first column, central estimate in the second, lower in the third, and upper in the fourth. If Plot = TRUE, a return level plot is also returned.

Author(s)

Anthony Hammond

Examples

```
#Get an ungauged pooling group:
Pool.203018 <- Pool(GetCDs(203018), exclude = 203018)
#Use the function to quantify the central estimate and uncertainty
Uncertainty(Pool.203018, qmed = QMED(GetCDs(203018)))
#Form a pooling group with subject site included.
Pool.203018 <- Pool(GetCDs(203018))
#Quantify the central estimate and uncertainty
Uncertainty(Pool.203018, Gauged = TRUE)
```

WeightsGLcv

Description

Provides the gauged Lcv weights for each site in a pooling group

Usage

```
WeightsGLcv(x)
```

Arguments

```
х
```

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

A data frame with site references in the first column and associated weights in the second

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form a gauged pooling group, and estimate gauged Lcv
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051)
WeightsGLcv(Pool.27051)
```

Description

Provides the gauged LSkew weights for each site in a pooling group

Usage

WeightsGLSkew(x)

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

A data.frame with site references in the first column and associated weights in the second

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form a gauged pooling group, and estimate gauged LSkew
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051)
WeightsGLSkew(Pool.27051)
```

WeightsUnLcv Site ungauged linear coefficient of variation (Lcv) weightings

Description

Provides the ungauged Lcv weights for each site in a pooling group

Usage

WeightsUnLcv(x)

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

A data.frame with site references in the first column and associated weights in the second

WeightsUnLSkew

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form an ungauged pooling group, and estimate ungauged Lcv
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051, exclude = 27051)
WeightsUnLcv(Pool.27051)
```

WeightsUnLSkew Site ungauged linear skewness (LSkew) weightings

Description

Provides the ungauged LSkew weights for each site in a pooling group

Usage

WeightsUnLSkew(x)

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

A data.frame with site references in the first column and associated weights in the second

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form an ungauged pooling group, and estimate ungauged LSkew
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051, exclude = 27051)
WeightsUnLSkew(Pool.27051)
```

WGaugLcv

Description

Calculates the gauged weighted Lcv from a pooling group (enhanced single site)

Usage

WGaugLcv(x)

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

the gauged weighted Lcv from a pooling group

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form a gauged pooling group, and estimate gauged Lcv
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051)
WGaugLcv(Pool.27051)
```

WGaugLSkew	Gauged pool weighted linear skewness (LSkew)
------------	--

Description

Calculates the gauged weighted LSkew from a pooling group (enhanced single site)

Usage

WGaugLSkew(x)

WungLcv

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

the gauged weighted LSkew from a pooling group

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form a gauged pooling group, and estimate gauged LSkew
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051)
WGaugLSkew(Pool.27051)
```

WungLcv

Ungauged pool weighted linear coefficient of variation (Lcv)

Description

Calculates the ungauged weighted Lcv from a pooling group

Usage

WungLcv(x)

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

the ungauged weighted Lcv from a pooling group

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form an ungauged pooling group, and estimate ungauged Lcv
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051, exclude = 27051)
WungLcv(Pool.27051)
```

WungLSkew	Ungauged pool weighted linear skewness (LSkew)

Description

Calculates the ungauged weighted LSkew from a pooling group

Usage

WungLSkew(x)

Arguments

х

pooling group derived with the Pool() function

Details

Weighting method as according to Science Report: SC050050 - Improving the FEH statistical procedures for flood frequency estimation

Value

the ungauged weighted LSkew from a pooling group

Author(s)

Anthony Hammond

Examples

```
#Get some CDs, form an ungauged pooling group, and estimate ungauged LSkew
CDs.27051 <- GetCDs(27051)
Pool.27051 <- Pool(CDs.27051, exclude = 27051)
WungLSkew(Pool.27051)
```

Zdists

Description

Calculates the goodness of fit score for pooling groups.

Usage

Zdists(x)

Arguments

Х

pooling group derived from the Pool() function

Details

The goodness of fit measure provides a Z-Score which quantifies the number of standard deviations from the mean of a normal distribution. To determine goodness of fit for a given distribution (assume GEV for this example), 500 pooling groups are formed which match the number of sites and samples sizes of the pooling group of interest. These are formed by simulation with the GEV distribution having LCV and LSKEW which are the weighted mean LCV and LSKEW of the pooling group (weighted by sample size) and a median of 1. The weighted mean L-Kurtosis of the observed pooling group (tR4) is compared to the mean and standard deviation (sd) of L-Kurtosis from the simulated pooling groups (tR4_Dist) by calculating the associated Z-score: (tR4 – mean(tR4_Dist)) / sd(tR4_Dist). The fit of the distribution can be considered acceptable if the absolute Z-Score is less than 1.645 (essentially a hypothesis test with alpha level equal to 0.1). This is done for all candidate distributions and the lowest absolute score is considered the best fit.

NOTE: This is slightly different from the zdist function described in the science report 'Improving the FEH statistical procedures for flood frequency estimation, Environment Agency (2008)'. That function assumes a theoretical LKurtosis as a function of the pooled LSKEW to compare with a distribution of LKurtosis from simulated pooling groups. This means that the Gumbel distribution cannot be compared (hence the change).

Value

A list with the first element a data.frame of four Z-Scores related to the columns; "GEV", "GenLog", "Gumbel", and "Kappa3". The second element is a character stating which has the best fit.

Author(s)

Anthony Hammond

Zdists

Examples

```
#Get CDs, form a pooling group and calculate the Zdist
CDs.203018 <- GetCDs(203018)
Pool.203018 <- Pool(CDs.203018)
Zdists(Pool.203018)
```

Index

* datasets AMSP, 8 NRFAData, 77 QMEDData, 88 ThamesPQ, 99 UKOutline, 102 AddGauge, 4 AggDayHour, 5 AMImport, 6 AMplot, 7 AMSP, 8 AnnualStat, 8 ARF, 10 BFI, 11 Bootstrap, 12 CDsXML, 13 ConvertGridRef, 14 DDF, 15 DDF99, 16 DDF99Pars, 17 DDFExtract, 18 DDFImport, 19 DesHydro, 20 DeTrend, 21 DiagPlots, 22 DonAdj, 23 EncProb, 24 ERPlot, 25 EVPlot, 26 EVPlotAdd, 27 EVPool, 29 FlowDurationCurve, 30 FlowSplit, 32 GenLogAM, 33

GenLogEst, 34 GenLogGF, 35 GenLogPars, 36 GenParetoEst, 37 GenParetoGF, 38 GenParetoPars, 39 GenParetoPOT, 40GetAM, 41 GetCDs, 42 GetDataEA_QH, 42 GetDataEA_Rain, 44 GetDataMetOffice, 46 GetDataNRFA, 47 GetDataSEPA_QH, 48 GetDataSEPA_Rain, 49 GetQMED, 50 GEVAM, 51 GEVEst, 52 GEVGF, 53 GEVPars, 54 GoFCompare, 55 GoFComparePool, 56 GumbelAM, 57 GumbelEst, 58 GumbelGF, 59 GumbelPars, 59 H2. 60 HydroPlot, 61 Kappa3AM, 63 Kappa3Est, 64 Kappa3GF, 65 Kappa3Pars, 66 Lcv, 67 LcvUrb, 67

LKurt, 68 LMoments, 69 LRatioChange, 70

INDEX

LSkew, 71 LSkewUrb, 72 MonthlyStats, 73 NGRDist, 74 NonFloodAdj, 75 NonFloodAdjPool, 76 NRFAData, 77 OptimPars, 78 Pool, 79 PoolEst, 80 PoolSmall, 82 POTextract, 84 POTt, 85 QMED, 87 QMEDData, 88 QMEDDonEq, 89 QMEDfseSS, 90QMEDLink, 91 QMEDPOT, 92 QuickResults, 93 Rating, 94 ReFH, 95 SCF, 97 SimData, 98 ThamesPQ, 99 TrendTest, 100 UAF, 101 UEF, 102 UKOutline, 102 Uncertainty, 103 WeightsGLcv, 105 WeightsGLSkew, 105 WeightsUnLcv, 106 WeightsUnLSkew, 107 WGaugLcv, 108 WGaugLSkew, 108 WungLcv, 109 WungLSkew, 110

114

Zdists, 111